



AIRGAINCONNECT® MEGAFI 2

Software Manual v3.8.x



Airgain, Inc provides this documentation in support of its products for the internal use of its current and prospective customers. The publication of this document does not create any other right or license in any party to use and content in or referred to in this document and any modification or redistribution of this document is not permitted.

While efforts are made to ensure accuracy, typographical and other errors may exist in this document. Airgain, Inc reserves the right to modify or discontinue its products and to modify this and any other product documentation at any time.

All Airgain, Inc products are sold subject to its published Terms and Conditions, subject to any separate terms agreed with its customers. No warranty of any type is extended by publication of this documentation, including, but not limited to, implied warranties or merchantability, fitness for a particular purpose and non-infringement.

Copyright© 2026 All Rights Reserved. Registered Trademarks TM Airgain, Inc. Airgain, AirgainConnect, NimbeLink, and their associated logos are trademarks or registered trademarks of Airgain, Inc.



Table of Contents

1	INTRODUCTION.....	4
1.1	OBJECTIVES	4
1.2	CONVENTIONS	4
1.3	RELATED DOCUMENTS	6
1.4	ABBREVIATIONS AND ACRONYMS	6
1.5	ABOUT OPENWRT AND MISSION CONTROL	7
1.6	ABOUT THIS DOCUMENT	7
1.7	SUPPORT	8
2	MISSION CONTROL.....	9
2.1	ACCESSING MISSION CONTROL VIA ETHERNET CONNECTION	9
2.2	INITIAL CONNECTION TO AC-MEGAFi 2 VIA WI-FI	13
2.3	NAVIGATING MISSION CONTROL.....	18
2.3.1	<i>Top Banner</i>	18
2.3.2	<i>Navigation Pane</i>	19
2.4	WORKING WITHIN MISSION CONTROL	20
2.4.1	<i>Save Options</i>	21
2.4.2	<i>Save</i>	21
2.4.3	<i>Managing Unapplied Changes</i>	22
2.4.4	<i>Save & Apply</i>	23
2.4.5	<i>Apply Unchecked</i>	24
2.4.6	<i>Reset or Revert</i>	24
2.4.7	<i>Overview Page</i>	25
3	CONFIGURATION SETTINGS	30
3.1	CHANGING APN (ACCESS POINT NAME)	30
3.2	CHANGING LAN IP ADDRESS	32
3.3	FLASH/UPDATE FIRMWARE.....	34
3.4	BACKUP EXISTING CONFIGURATION.....	38
3.5	LOAD CONFIGURATION FROM FILE	40
3.6	CHANGE PASSWORD.....	43
3.7	FACTORY DEFAULTS VIA MISSION CONTROL.....	44
3.8	VEHICLE SHUTDOWN DELAY.....	46
3.9	REBOOT.....	47
3.10	WIRELESS SETTINGS.....	48
3.10.1	<i>Verify Wi-Fi Settings</i>	49
3.10.2	<i>Change Wi-Fi Settings</i>	51
3.10.3	<i>Guest Wi-Fi Settings</i>	55
3.11	NAT VS. PASSTHROUGH MODE	59
3.12	BAND LOCK, BAND 1, BAND 30, AND MAXIMIZE BAND 14 SETTINGS	66
3.12.1	<i>Band Lock Setting</i>	66
3.12.2	<i>Band 1 and Band 30 Settings</i>	68
3.12.3	<i>Maximize Band 14 Usage</i>	68
3.13	SSH ACCESS.....	69
3.14	GPS OUTPUT CONFIGURATION	72

3.14.1	GPS Server	73
3.14.2	GPS Internal Reporting.....	75
3.14.3	GPS Output.....	79
3.15	WAN/LAN PORT MODE	82
3.16	LCD CONFIGURATION	82
3.17	SNMP	85
3.18	CLIENT ISOLATION	87
3.19	FAILOVER PRIMARY CONNECTION	89
3.20	NETWORK SCAN.....	92
3.21	IPSEC VPN	95
3.22	MODIFY HOSTNAME	99
3.23	eSIM CONFIGURATION	102
3.23.2	Disable and Delete eSIM Profile	114
3.23.3	Purge eSIM Profile	118
3.24	DOWNLOAD TROUBLESHOOTING FILES	119
3.25	FIREWALL	120
3.25.1	Port Forward	121
3.25.2	Traffic Rule.....	124
3.26	FIREWALL DIAGNOSTICS	129
3.27	SMART QUEUE MANAGEMENT (SQM QoS)	133
3.28	TIME ZONE	135
3.29	API CONFIGURATION.....	137
4	CUSTOMER SUPPORT.....	141

Revision History

Rev	Iteration	Description	Date
1	1	Initial Release for v3.1.6	5/21/2025
1	2	Release for v3.3.x	7/24/2025
1	3	Release for v3.4.x	10/6/2025
1	4	Release for v3.5.x	12/9/2025
1	5	Release for v3.6.x	1/9/2026
1	6	Release for v3.7.x	2/18/2026
1	7	Release for v3.8.x	6/26/2026
1	8	Release for v3.8.x	7/2/26

1 Introduction

The purpose of this manual is to assist the user in operating the AC-MegaFi 2 wireless WAN HPUE router. This manual will help the user configure and operate the device using the device's Mission Control software.

For assistance in implementing or installing the AC-MegaFi 2 device, please refer to the separate AC-MegaFi 2 User Manual.

Note: All images used in this document are used only for displaying examples of configurations and may not reflect the users' current device.

1.1 Objectives

The objectives of this document are:

- to describe the software environment and basic understanding of interacting and configuring AC-MegaFi 2 for your use.
- to provide the necessary information to understand the device and the options available in the AC-MegaFi 2; and
- to support implementing the necessary configuration for your communications environment and for your continued use.
- This document expects the user to have basic computer skills and to be familiar with using and navigating with a web browser, to be knowledgeable in networking concepts, and to be able to configure a traditional wired or wireless router for their communications environment.

1.2 Conventions

This document follows certain typographic conventions, outlined below:

Bold

Is used for directories, filenames, commands, and options. All terms shown in bold are typed literally.

Bold Italic

Is used to show generic arguments and options; these should be replaced with user-supplied values.

Italic

Is used to highlight comments in examples.

Constant Width

Is used to show the contents of files or the output from commands.



1.3 Related Documents

- The AC-MegaFi 2 User Manual: <https://airgain.com/wp-content/uploads/2026/03/MegaFi-2-User-Guide.pdf>
- The AC-MegaPortal User Manual: <https://airgain.com/wp-content/uploads/2026/03/MegaPortal-Manual.pdf>
- For other AC-MegaFi 2 documentation, please go to <https://airgain.com/products/megafi-2-hpue/>

1.4 Abbreviations and Acronyms

The following table provides a list of abbreviations and acronyms that are referenced throughout this manual.

Table 1 – Abbreviations and Acronyms

APN	Access Point Name	NTPD	Network Time Protocol Daemon
DHCP	Dynamic Host Configuration Protocol	PD	Prefix Delegation
DNS	Domain Name System	PID	Process Identification Number
DDNS	Dynamic Domain Name System	PIN	Personal Identification Number
GNSS	Global Navigation Satellite System	Ping	Packet Internet Groper
GPS	Global Positioning System	PoE	Power over Ethernet
HTTPS	Hypertext Transfer Protocol Secure	PPP	Point-to-Point Protocol
ICCID	Integrated Circuit Card Identifier	PPPoE	Point-to-Point Protocol over Ethernet
ICMP	Internet Control Message Protocol	RA	Route Advertisement
IGMP	Internet Group Management Protocol	SIM	Subscriber Identity Module
IMEI	International Mobile Equipment Identity	SLAAC	Stateless Address Auto Configuration

IMSI	International Mobile Subscriber Identity	SSH	Secure Shell
IP	Internet Protocol	SSID	Service Set Identifier
IPSEC	Internet Protocol Security	STP	Spanning Tree Protocol
LAN	Local Area Network	TAIP	Trimble ASCII Interface Protocol
LTE	Long-Term Evolution	TFTP	Trivial File Transfer Protocol
MAC address	Media Access Control address	UDP	User Datagram Protocol
MCBV	Modem Configuration Band Values	UTC	Coordinated Universal Time
MCLBV	Modem Configuration LTE Band Values	UUID	Universally Unique Identifier
MTU	Maximum Transmission Unit	VLAN	Virtual LAN
NAT	Network Address Translation	VPN	Virtual Private Network
NDP Proxy	Neighbor Discovery Protocol Proxy	HPUE	High Power User Equipment

1.5 About OpenWRT and Mission Control

The OpenWRT software that the AC-MegaFi 2 system uses is an open-source project that provides a full-featured operating system for embedded devices. Airgain's implementation of OpenWRT LuCI—the dashboard that allows you to configure and manage the AC-MegaFi 2 suite of software and devices from a single computer—is known as Mission Control.

1.6 About this Document

This document is in three parts: part 1 is the Introduction, part 2 is Mission Control, and part 3 is Configuration Settings.

You are currently in the introduction. Part 2, Mission Control, provides information on accessing, navigating, and working within the system, including how to save your work. We cannot emphasize enough how important it is that you understand how to navigate and work within the system, as it is a new experience for many. Indeed, if



this is your first time using this document and/or accessing the dashboard, we recommend reading it in its entirety and reaching out with any questions.

Part 3 is Configuration Settings. This section details the configuration settings users can make such as password, Wi-Fi, firmware updates, APN, IP address and others.

1.7 Support

Airgain's support desk is always ready to help you with any support issues or requests. If you encounter any problems, need clarification, or have feedback, recommendations, or suggestions, please contact us at connectivity.support@airgain.com.

2 Mission Control

Mission Control is the built-in web interface that provides information about the AC-MegaFi 2 router and allows the user to configure settings to their preferences. All configuration and management are done via your workstation or laptop computer's web browser, and you will need to be locally connected to the device via Ethernet to a LAN port, or by utilizing its Wi-Fi capability in the admin dashboard. Remote access to Mission Control is also possible through MegaPortal. Please refer to the MegaPortal Manual for guidance on remote access to Mission Control.

2.1 Accessing Mission Control via Ethernet Connection

To access Mission Control, you will need both your admin password and the default factory LAN IP, 192.168.113.1. The password is printed on the label on the bottom of your AC-MegaFi 2 or on the LCD display screen.

Note: Use the defined password and/or IP address if it has been changed for your environment.

Note: Beginning in firmware release version 3.4.1, once the default password is changed, the password will no longer be displayed on the display screen. To re-enable this device password to be displayed back on the display screen, go to Section 3.16 LCD Configuration for details.

1. Connect an Ethernet cable between your workstation computer or laptop and LAN port 1 on the AC-MegaFi 2.
2. Open a web browser to the following URL address: <https://192.168.113.1>
3. The first time you try to connect to AC-MegaFi 2, a connection warning screen will display as shown below. Accept the connection warning by clicking on

Advanced.




Figure 1 – AC-MegaFi 2 connection warning screen

4. A second warning screen will be displayed as shown below. Click on **Continue to 192.168.113.1 (unsafe)** link to proceed.





Figure 2 – AC-MegaFi 2 connection warning – second screen

5. The AC-MegaFi 2's Mission Control GUI login page will now be displayed.
 - a. Enter the password as found on the bottom label or on the LCD display screen of the AC-MegaFi 2 on the Mission Control login page.

Note: The username always defaults to **admin**.

- b. Click **Login** to proceed.



The screenshot shows the 'Mission Control' login interface. At the top, there's a 'Current Status' section with a table of device information:

Connected	Signal Strength	Band	Access Point Name	WAN IP Address	Local IP Address
FirstNet	(Excellent)	14	firstnet-broadband	10.83.30.8	192.168.113.1

Below the status section is the 'Log In' section. It prompts the user to enter their username and password. The 'Username' field is pre-filled with 'admin'. The 'Password' field is empty. There are 'Login' and 'Reset' buttons at the bottom right.

Figure 3 – Mission Control Log-In screen

6. When logging in for the first time, the EULA (End User License Agreement) will be displayed.
7. Fill out the requested information and click **Accept** to continue.



The screenshot shows the 'End User License Agreement' screen. It contains several input fields for user information:

- First Name
- Last Name
- Company (optional)
- Phone (optional)
- E-Mail


At the bottom right, there are 'Accept' and 'Decline' buttons.

Figure 4 – End User License Agreement screen

8. Also, as part of first-time login to AC-MegaFi 2, the user will be required to change the default login password.
 - a. Proceed to change the default password to a 'Strong' password in the **Password** field.

Note: The device will not accept weak passwords. Password must meet the following requirements: a minimum length of 10 characters and a randomized complexity of lowercase letters, uppercase letters, and numbers.


- b. Confirm the new password in the **Confirmation** field, then click on **Save**.



The screenshot shows the 'Router Password' configuration page. At the top, there are tabs for 'Router Password', 'SSH Access', and 'SSH-Keys'. The 'Router Password' tab is active. Below the tabs, the title 'Router Password' is followed by a subtitle: 'Changes the administrator password for accessing the device'. There are two input fields: 'Password' and 'Confirmation'. Both fields contain masked characters (dots). To the right of each field is a small blue icon with a white asterisk. Below the input fields, the text 'Password strength: Strong' is displayed in green. In the bottom right corner, there is a red 'Save' button.

Figure 5 – Change Router Password screen

9. The user will now be redirected to Mission Control's Overview page.



The screenshot shows the 'Mission Control Overview' page. On the left is a sidebar with a menu: Overview, Device, Networking, DHCP Leases, Interfaces, System Settings, and Logout. The 'Overview' tab is selected. Below the menu is a blue 'Refreshing' button. The main content area is titled 'Overview' and contains three sections: 'Device', 'Modem Status', and 'Networking'. The 'Device' section lists various hardware and network details. The 'Modem Status' section shows connection mode, network, and status. The 'Networking' section includes a 'DHCP Leases' table with columns for Hostname, IPv4 address, MAC address, and Lease time remaining.

Device			
Model	SHIELD MegaFi 2		
Serial Number	250601000632		
IMEI	359172391063678		
Phone Number	858.914.8261		
ICCID (SIM)	89011003330143979960		
ESIMID	89049032000001000000212986270921		
Uptime	1d 20h 2m 50s		
Cloud Connection Status	Connected (7/24/2025, 10:44:10 AM)		
TX Bytes (since last power cycle)	218.75 MB (742319 Pkts.)		
RX Bytes (since last power cycle)	1.39 GB (1627490 Pkts.)		
Memory Used	74.46 MiB / 235.02 MiB (31%)		
Location (Lat, Lon)	0.000000, 0.000000		

Modem Status			
Connection Mode	5G		
Home Network	FirstNet		
Current SIM in use	physical SIM		
Current APN in use	firstnet-broadband		

Networking			
Connection Status		LTE	5G
Band		Connected	Not connected
CID (Serving Cell ID)		14	
PCI (Physical Cell ID)		79474863	
Bandwidth		388	
RSRP		-88	
RSRQ		-9	
RSSI		-60	
TX Power		21	
MIMO status		4x4-MIMO	not_attach

DHCP Leases			
Active DHCPv4 Leases			
Hostname	IPv4 address	MAC address	Lease time remaining

Figure 6 – Mission Control – Overview page

10. First-time router configuration is now complete!

2.2 Initial Connection to AC-MegaFi 2 via Wi-Fi

To access Mission Control, you will need both your **admin password**, and the default factory **LAN IP, 192.168.113.1**. The password is printed on the label on the bottom of your AC-MegaFi 2 or on the LCD display screen.

Notes:

- Use the defined password and/or IP address if it has been changed for your environment.
- The example shown below was accomplished using a Windows (10/11) PC. The steps should be similar using a different OS.
- Handheld devices can automatically connect to AC-MegaFi 2's Wi-Fi by scanning the QR code from the LCD Display screen, but it may become difficult to configure certain settings. Therefore, it is highly recommended to configure settings using a computer workstation or laptop.

To connect to AC-MegaFi 2 via Wi-Fi using a PC:

1. Go into your PC's **Network & internet > Wi-Fi** settings to add a new Wi-Fi connection.
2. Select your AC-MegaFi 2 device by looking for its default SSID under **Show available networks** by selecting it. The default SSID and its password are printed on the device's label located underneath the device or it can be found on the LCD display screen.



Figure 7 – Windows network & internet window showing list of available Wi-Fi networks

3. The **Connect automatically** box may or may not be checked by default. Select as desired then click on **Connect**.



Figure 8 – Wi-Fi Network Connection – Connect automatically option

4. **Enter the network security key** (default SSID password), then click on **Next**.




Figure 9 – Wi-Fi Network Connection – Enter network security key

5. If the connection is successful, it will say **Connected, secured**.



Figure 10 – Wi-Fi Network Connection – Successful connection

6. Open a web browser to the following URL address: <https://192.168.113.1>
7. The first time you try to connect to AC-MegaFi 2, a connection warning screen will display as shown below. Accept the connection warning by clicking on **Advanced**.




Figure 11 – Warning message – Connection not private

8. A second warning screen will be displayed as shown below. Click on **Continue to 192.168.113.1 (unsafe)** link to proceed.





Figure 12 – Warning message – Continue to IP address

9. The AC-MegaFi 2's Mission Control GUI login page will now be displayed.
 - a. Enter the password as found on the bottom label or on the LCD display of the AC-MegaFi 2 on the Mission Control login page.

Note: The username always defaults to admin. 9b.

- b. Click **Login** to proceed.



The screenshot shows the 'Mission Control' login interface. At the top, there's a 'Current Status' section with a table of device information:

Connected	Signal Strength	Band	Access Point Name	WAN IP Address	Local IP Address
FirstNet	(Excellent)	14	firstnet-broadband	10.83.30.8	192.168.113.1

Below this is the 'Log In' section with the instruction 'Please enter your username and password.' It features two input fields: 'Username' (pre-filled with 'admin') and 'Password'. At the bottom right of the login section are 'Login' and 'Reset' buttons.

Figure 13 – Mission Control – Log In page

10. When logging in for the first time, the EULA (End User License Agreement) will be displayed.
 - a. Fill out the requested information and click **Accept** to continue.



The screenshot shows the EULA form with the following fields: 'First Name', 'Last Name', 'Company (optional)', 'Phone (optional)', and 'E-Mail'. Each field has a corresponding input box. At the bottom right, there are 'Accept' and 'Decline' buttons.

Figure 14 – End-User License Agreement (EULA)

11. Also, as part of first-time login to AC-MegaFi 2, the user will be required to change the default login password.
 - a. Proceed to change the default password to a 'Strong' password in the **Password** field.

Note: The device will not accept weak passwords. Password must meet the following requirements: a minimum length of 10 characters and a randomized

complexity of lowercase letters, uppercase letters, and numbers.

12. Confirm the new password in the **Confirmation** field, then click on **Save**.

The screenshot shows the 'Router Password' configuration screen. At the top, there are tabs for 'Router Password', 'SSH Access', and 'SSH-Keys'. The 'Router Password' tab is active. Below the tabs, the title 'Router Password' is followed by a subtitle 'Changes the administrator password for accessing the device'. There are two input fields: 'Password' and 'Confirmation', both masked with dots. To the right of each field is a small icon with an asterisk. Below the fields, it says 'Password strength: Strong' in green. A blue 'Save' button is located in the bottom right corner.

Figure 15 – Change Router Password screen

13. The user will now be re-directed to Mission Control's Overview page.

The screenshot shows the 'Mission Control - Overview' page. On the left is a sidebar with navigation links: Overview, Device, Networking, DHCP Leases, Interfaces, System Settings, and Logout. The 'Overview' link is highlighted. Below the sidebar is a 'Refreshing' button. The main content area is titled 'Overview' and contains three sections: 'Device', 'Modem Status', and 'Networking'. The 'Device' section lists various identifiers and connection details. The 'Modem Status' section shows connection mode, network, and SIM information. The 'Networking' section includes a 'DHCP Leases' table with columns for Hostname, IPv4 address, MAC address, and Lease time remaining.

DHCP Leases			
Active DHCPv4 Leases			
Hostname	IPv4 address	MAC address	Lease time remaining

Figure 16 – Mission Control – Overview page

14. First-time router configuration is now complete!

2.3 Navigating Mission Control

Once logged into Mission Control, the first page the user will see is the **Overview** page.

Overview

Device

Model: SHIELD MegaFi 2

Serial Number: 250601000632

IMEI: 359172391063678

Phone Number: 858.914.8261

ICCID (SIM): 89011003330143979960

ESIMID: 89049032000001000000212986270921

Uptime: 1d 20h 2m 50s

Cloud Connection Status: Connected (7/24/2025, 10:44:10 AM)

TX Bytes (since last power cycle): 218.75 MB (742319 Pkts.)

RX Bytes (since last power cycle): 1.39 GB (1627490 Pkts.)

Memory Used: 74.46 MiB / 235.02 MiB (31%)

Location (Lat,Lon): 0.000000,0.000000

Modem Status

Connection Mode: 5G

Home Network: FirstNet

Current SIM in use: physical SIM

Current APN in use: firstnet-broadband

Connection Status: LTE Connected 5G Not connected

Band: 14

CID (Serving Cell ID): 79474863

PCI (Physical Cell ID): 388

Bandwidth: 10

RSRP: -88

RSRQ: -9

RSSI: -60

TX Power: 21

MIMO status: 4x4-MIMO not_attach

Networking

DHCP Leases

Active DHCPv4 Leases

Hostname	IPv4 address	MAC address	Lease time remaining
----------	--------------	-------------	----------------------

Figure 17 – Mission Control – Overview page

2.3.1 Top Banner

The top banner area, which is consistently displayed on every navigation page, will show the current Network mode and cellular signal strength information towards the top right area.



Figure 18 – Mission Control – top banner

Table 2 – Network Mode and Signal Strength

Network Mode	NAT (default) or Passthrough mode
Signal Strength	The number of cellular signal strength bars that should match up with the bars on the device LCD Display screen.

2.3.2 Navigation Pane

The navigation pane on the left consists of a two-level menu system:




Figure 19 – Mission Control Navigation Pane – Overview menu

1. In the main **Overview** page, the Top-level menu section consists of four on-page topics: **Device**, **Networking**, **System Settings**, and **Logout**.
2. If any, the second-level sub-menu contains on-page quick links.

For example, Figure 19 shows the top-level **Networking** menu item with its second-level sub-menu items of **DHCP Leases** and **Interfaces**. Clicking on any of those options will take you to that area of the current Top-level selection.

3. Selecting the **Logout** option will log you out of Mission Control.

When the user navigates into Expert Configuration mode by clicking on the **Expert Configuration** button, located in the **System Settings** under **Admin Tools**, the navigation pane on the left exposes different selectable options and lands the user inside the **General** page (Second-level page) under **Status** (Top-level menu).




Figure 20 – Mission Control Navigation Pane – Expert Configuration mode menu

4. There is a link back to the main **Overview** page at the top. Click on it to go back to the main **Overview** page.
5. The Top-level menu section consists of four new topics with links to different pages under each: **Status**, **System**, **Network**, and **Logout**.
6. If any, the second-level sub-menu in this area contains a variable number of page links.

For example, Figure 20 shows the top-level **Status** menu item with its second-level sub page links to **General**, **Routing**, **Firewall**, **System Log**, **Processes**, **Channel Analysis**, etc. Clicking on any of those page link options will take you to that page of the current Top-level selection.

7. Selecting the **Logout** option will log you out of Mission Control.

2.4 Working within Mission Control

When working within Mission Control, you will need to perform actions such as **Edit**, **Save**, **Discard**, **Reset**, etc. To both ease this process and to ensure efficiency of workflow, changes made are stored as **Unapplied Changes** rather than being actioned and implemented immediately. In doing so, if your workflow is interrupted or if you inadvertently navigate away from a page without applying your changes, any work done to date is not discarded and accidentally lost.

Subsequently, when you are ready to apply these unapplied changes, they can either be saved and applied, reset/discarded, or revert/cancelled in one stroke rather than piecemeal, one at a time. This process also lets you check, verify, and manage the list of queued changes prior to updating the system, and, depending on the changes required, avoids slowing your workflow.

2.4.1 Save Options

Within Mission Control, all changes and saves must be applied manually—there are no automatic save or apply options. Typically, there are three save options: **Save**, **Save & Apply**, and **Apply Unchecked**; plus, non-save options such as **Reset**, **Dismiss**, **Revert**, etc.




Figure 21 – Mission Control – Save options

The action buttons you see will depend on where you are in the system and what changes you have made. We will look at these in more detail below, starting with **Save**.




Figure 22 – Mission Control – Save options

2.4.2 Save

Though the **Overview** page presents most of the basic admin functionality in a single scrolling page, you may need to navigate between, and make changes to, multiple pages within Mission Control itself. The **Save** button allows you to save your changes as you go. In contrast, without this save option, if you navigated away from a page without saving your changes, these would then be discarded and lost, and current applied settings and values would remain unchanged. However, it is important to note that saving changes does not apply/commit them to the system (i.e., no updates occur as a result of saving changes).

Instead, saving any changes adds them as pending to the Unapplied Changes list as shown below.




Figure 23 – Navigation pane showing pending Unapplied Changes

Once saved as **Unapplied Changes**, you can then:

- carry out additional work on the current page or navigate away to a different page and continue your tasks until you are ready to apply all changes.
- manage your unapplied changes.
- save and apply your unapplied changes.

2.4.3 Managing Unapplied Changes

To view or manage your unapplied changes:

1. Click on the **Unapplied Changes** button and the **Configuration/Changes** dialog will show, listing all queued changes as shown below. Also, the status of each item is indicated by its color, per the legend.
2. From here, you have several buttons: **Close**, **Save & Apply** (**Apply unchecked** is in the drop-down menu), and **Revert** or **Reset**




Figure 24 – Configuration/Changes showing button options

- a. **Close** – will close this dialog window.
- b. **Save & Apply** – will apply the changes, clear the Configuration/Changes list, close the dialog window, and you will then see the Apply configuration changes countdown popup.

Note: Unlike performing a **Save & Apply** from the main dashboard, because these items have already been saved once (the initial save added them to the unapplied changes queue), no second click is required to initiate these changes. A single click on the **Save & Apply** button will commit all changes and the countdown will commence.

- c. **Revert/Reset** will cancel all unapplied changes, clears the list of any pending changes, and displays the “changes have been reverted” message as a popup, and then takes you back to the Mission Control dashboard where all settings remain unchanged.

2.4.4 Save & Apply

When you are ready to apply your unapplied changes, click on **Save & Apply**. This will then apply all unapplied changes to the system and update your current configuration.

IMPORTANT: Please allow adequate time for changes to update and ensure continuous power is supplied to the AC-MegaFi 2 during any updates.

2.4.5 Apply Unchecked

When updating certain attributes, such as the LAN IP address or other configurations, there is often a time delay between events, (e.g., a change in the LAN IP that uses DHCP) so there may be a delay between connecting to the new IP and subsequent assignment of new DHCP addresses. In such cases, the system will attempt to check that both communication and function are maintained. However, if, during this check, the system determines that either would be lost because of the change, it will trigger the **“Configuration has been rolled back!”** alert. **Apply unchecked** allows us to avert this by applying pending changes without performing communication and function checks.

1. Click on the **Save & Apply** button arrow and the popup, as shown below, will open.
2. Click on **Apply unchecked** and the dropdown will close, the button label will change to **Apply unchecked**, and the button color will change to red as shown below.
3. A second click, on the now **Apply unchecked** apply the changes and the Applying configuration changes countdown will initiate.




Figure 25 – Configuration/Changes showing applied configuration changes

2.4.5.1 Cancelling Apply Unchecked

To cancel the **Apply unchecked** button (and revert to the default **Save & Apply**):


1. Click on the arrow on the **Apply unchecked** button to display the popup as shown above.
2. Click on **Save & Apply**. The button's label will revert to **Save & Apply**, and the button's color will change to blue.

2.4.6 Reset or Revert

Clicking on **Reset** or **Revert** will cancel all unapplied changes, clear this list, return on-page settings to their current values, and leave the current settings and configuration in their present state.

2.4.7 Overview Page

As previously pointed out above, the top-level menu, the user can see direct links to **Device**, **Networking**, **System Settings** all listed in the left-hand pane and detailed information and statistics for each of these pages within the main window. The Logout button function is also listed at the bottom.



The screenshot shows the Mission Control Overview page. On the left is a sidebar menu with options: Overview, Device, Networking, DHCP Leases, Interfaces, System Settings, and Logout. A 'Refreshing' button is visible below the menu. The main content area is titled 'Overview' and contains three sections: Device, Modem Status, and Networking.

Device

Model	SHIELD MegaFi 2
Serial Number	250601000632
IMEI	359172391063678
Phone Number	858.914.8261
ICCID (SIM)	89011003330143979960
ESIMID	89049032000001000000212986270921
Uptime	1d 20h 2m 50s
Cloud Connection Status	Connected (7/24/2025, 10:44:10 AM)
TX Bytes (since last power cycle)	218.75 MB (742319 Pkts.)
RX Bytes (since last power cycle)	1.39 GB (1627490 Pkts.)
Memory Used	74.46 MiB / 235.02 MiB (31%)
Location (Lat, Lon)	0.000000, 0.000000

Modem Status

Connection Mode	5G
Home Network	FirstNet
Current SIM in use	physical SIM
Current APN in use	firstnet-broadband

	LTE	5G
Connection Status	Connected	Not connected
Band	14	
CID (Serving Cell ID)	79474863	
PCI (Physical Cell ID)	388	
Bandwidth	10	
RSRP	-88	
RSRQ	-9	
RSSI	-80	
TX Power	21	
MIMO status	4x4-MIMO	not_attach

Networking

DHCP Leases

Active DHCPv4 Leases

Hostname	IPv4 address	MAC address	Lease time remaining
----------	--------------	-------------	----------------------

Figure 26 – Mission Control – Overview page

The user may need to scroll down the main window to see all that is presented under **Overview**. Each of these areas are detailed below.

2.4.7.1 Device

For a detailed summary of the device, view the **Device** section. Right below is the **Modem Status** area for **Connection Mode** and **Connection Status**, as well as cellular network information and other statistics.

Overview

- Device**
- Networking
- DHCP Leases
- Interfaces
- System Settings
- Logout

Refreshing

Overview

Device

Model	SHIELD MegaFi 2
Serial Number	250601000632
IMEI	359172391063678
Phone Number	858.914.8261
ICCID (SIM)	89011003330143979960
ESIMID	89049032000001000000212986270921
Uptime	1d 20h 9m 38s
Cloud Connection Status	Connected (7/24/2025, 10:50:17 AM)
TX Bytes (since last power cycle)	219.81 MB (746713 Pkts.)
RX Bytes (since last power cycle)	1.40 GB (1632912 Pkts.)
Memory Used	73.22 MiB / 235.02 MiB (31%)
Location (Lat,Lon)	0.000000,0.000000

Modem Status

Connection Mode	5G+	
Home Network	FirstNet	
Current SIM in use	physical SIM	
Current APN in use	firstnet-broadband	
	LTE	5G
Connection Status	Connected	Not connected
Band	14	
CID (Serving Cell ID)	79474863	
PCI (Physical Cell ID)	388	
Bandwidth	10	
RSRP	-87	
RSRQ	-9	
RSSI	-60	
TX Power	24	
MIMO status	2x2-MIMO	not_attach

Figure 27 – Mission Control – Device

2.4.7.2 Networking

Clicking on **Networking** on the left-hand menu, the main window displays detailed information for **DHCP Leases** for connected hosts and **Interfaces: LAN, WAN, WAN6, WWAN**, and **Active Connections**.




Figure 28 – Mission Control – Networking

2.4.7.3 System Settings


Clicking on **System Settings** on the left-hand menu, the main window displays Admin Tools for:

- **Primary SIM**
- **Physical SIM APN selection**
- **Physical SIM custom APN** (exposed when the Physical SIM APN selection is set to Custom)
- **eSIM APN selection** (exposed when the Primary SIM is set to Automatic or an eSIM profile is configured on to the device)
- **eSIM custom APN** (exposed when the eSIM APN selection is set to Custom)
- **LAN IP**
- **WAN/LAN Port Mode**
- **Update Firmware**
- **Backup Existing Configuration**
- **Omit System Passwords**
- **Load Configuration from File**
- **Change Password**

- **Download Troubleshooting Files**
- **Factory Defaults**
- **Vehicle Shutdown Delay**
- **Expert Configuration**
- **Reboot**

The user has complete access to all these configuration features from this environment without needing to be in **Expert Configuration** mode.

Further details on how to use these settings will be discussed later in this document.



Admin Tools	
System Settings	
Primary SIM	physical SIM ▼
Physical SIM APN selection	Automatic ▼
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN ▼
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds ▼
Expert Configuration	Expert Configuration
Reboot	Reboot
Save & Apply ▼ Save Reset	

Figure 29 – Mission Control – System Settings

2.4.7.4 Logout

The user can log out of Mission Control by clicking on this button. This button is always visible in either Overview or Expert Configuration Mode located on the lefthand pane towards the bottom.




Figure 30 – Logout from Overview mode



Figure 31 – Logout from Expert Configuration mode

3 Configuration Settings

This section details the configuration settings users can make such as password, Wi-Fi, firmware updates, APN, IP address and others.

3.1 Changing APN (Access Point Name)

By default, the **Physical SIM APN selection** is set to **Automatic** and the **Physical SIM custom APN** will automatically detect and configure itself when a firstnet-broadband or an Enterprise (broadband) SIM is installed. If the user has a custom APN SIM card, do the following to manually change the **Physical SIM custom APN** in Mission Control:

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click the drop-down menu next to **Physical SIM APN selection** and select **Custom**. This will expose the **Physical SIM custom APN** setting field box.




Figure 32 – System Settings – Physical SIM APN selection

3. In the now exposed **Physical SIM custom APN** field box, hi-light the current entry, in this case it is **firstnet-broadband**, and hit the backspace key to delete it.

Figure 33 – System Settings – Physical SIM custom APN

4. Correctly type in the APN name associated with the SIM card into the **Physical SIM custom APN** field box with no extra spaces or hidden characters.

Hint: In firmware v3.7.0 and below, hit the **Enter** key after typing the APN name. Otherwise, the APN name will revert to its default or previous setting.

5. Click on the **Save & Apply** button at the bottom to confirm the APN name change.
6. Give the device a few minutes to successfully regain network connectivity.

Hint: After the device becomes available, it is advisable to issue a **Reboot** so the MegaFi or the device connected to the MegaFi in a Passthrough setup, properly receives the correct IP address and any other provisioned network settings. See Section 3.9 Reboot procedure.

7. To validate the custom IP address associated with your custom APN, navigate to **Overview > Networking** and verify the **WWAN IPv4** address under **Interfaces** and make sure it is what you are expecting. Or also validate the IP address on the device connected to the MegaFi in a Passthrough setup.





Figure 33 – Networking – WWAN IPv4 Address

3.2 Changing LAN IP Address

By default, the **LAN IP** address of the device is set to **192.168.113.1**. If the user needs to configure this setting to fit their network environment, do the following to make the change in Mission Control:

Note: In this environment, the system automatically sets a /24 or Class C network and will provide IP addresses to devices within this range.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. In the **LAN IP** field, hi-light the current entry, in this case, **192.168.113.1**, and hit the backspace key to delete it.



Admin Tools

System Settings

Primary SIM: physical SIM

Physical SIM APN selection: Automatic

LAN IP: 192.168.113.1

WAN/LAN Port Mode: WAN

Update Firmware: **Upload Firmware**

Figure 34 – System Settings – Changing LAN IP Address

3. Enter the new IP address in the custom field and hit the **Enter** key. Otherwise, it may revert to its default setting, or pre-configured IP address.
4. After clicking on **Enter** above, a popup window will warn the user that the system will be temporarily unreachable and that a manual reconfiguration of the URL address in the web browser address bar will be required to regain access to the device as soon as the change is committed.




Figure 35 – LAN IP address warning

5. Click on the **Save & Apply** button at the bottom to confirm the change.
6. A **Connectivity change** popup message will appear, warning the user that current access to the device will be interrupted if the user proceeds. The user is given options to either **Cancel**, **Apply with revert after connectivity loss**, or **Apply and keep settings**.




Figure 36 – Connectivity change popup message

- a. **Cancel** – will not proceed with committing the change but will keep unapplied changes pending and take the user back to step 5.
- b. **Apply with revert after connectivity loss** – will begin to commit the change but the user will have 90 seconds to regain access to the device using the new IP address. Otherwise, the setting will automatically revert to the previous setting. Another popup window (**Configuration changes have been rolled back!**) will ask the user to select **Dismiss**, **Revert changes**, or **Apply unchecked**.
 - **Dismiss** – will dismiss this popup window and take the user back to step 5.
 - **Revert changes** – will revert changes and take the user back to step 2.
 - **Apply unchecked** – will commit the change. Skip to step 7.




Figure 37 – Configuration changes have rolled back! popup message

- c. **Apply and keep settings** – will commit the change.
7. Selecting c (**Apply and keep settings**) will update the IP address. Give the device a few minutes to successfully regain network connectivity before attempting to reconnect to AC-MegaFi 2 via Mission Control.

Note: After proceeding with the LAN IP change, the user may need to retype the new IP address in the web browser address bar to regain access to the device.

3.3 Flash/Update Firmware

The user can either use Mission Control or MegaPortal (Cloud portal for AC-MegaFi 2), to update AC-MegaFi 2's firmware.

Important:

- Firmware updates for AC-MegaFi 2 are primarily only supported via MegaPortal. By default, the device is set to automatically update its firmware whenever there is a new version available in the cloud. However, this feature does not necessarily auto-update the device, but it acknowledges a new update is available and requires some user intervention to carry out the

update. To update the device using MegaPortal, please refer to the [MegaPortal User Manual](#).


- For special needs or requirements, and only with the assistance of Airgain Support, a user may update the firmware via Mission Control. To manually update the firmware for AC-MegaFi 2 via Mission Control, the firmware version-specific **BIN** file needs to be obtained from Airgain Support.

If the user cannot update from the Portal or requires an immediate update, do the following to update the device in Mission Control.

Assumption: The user has obtained the appropriate firmware (**BIN** file) from Airgain Support, it is loaded on a computer workstation or laptop, and it is directly connected to a LAN port on AC-MegaFi 2 or via its Wi-Fi connection.

Note: Uploading an incorrect file can render your device inoperable and may void warranty.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Upload Firmware** or **Flash image...** button next to **Update Firmware**.



Admin Tools	
System Settings	
Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Save & Apply Save Reset

Figure 38 – Firmware update – Upload Firmware button

3. On the pop-up **Uploading file...** window, click on **Browse** to locate the firmware file.



Figure 39 – Uploading file... - Browse button

- The firmware file should be a **BIN** type file, and, depending on the firmware version, around 47 MB or more.

Name	Status	Date modified	Type	Size
 Speedway_Sysupgrade_v3.4.1.bin		10/6/2025 2:29 PM	BIN File	48,642 KB

Figure 40 – Firmware update – Select the upgrade file

- Select the firmware file. The **Uploading file...** window now shows the selected file.



Figure 41 – Firmware update – Uploading the selected upgrade file

- Click on **Upload**, and the file will begin to upload.




Figure 42 – Firmware update – Status of upgrade file upload

- A new pop-up window **Flash image?** will ask the user to manually verify the checksum **SHA256** value displayed here, with the checksum **SHA256** value displayed inside the checksum file. Only continue if the values match.

Note: The **SHA256** value is unique to each version. In this example, this is the **SHA256** value for firmware version 3.4.1.




Figure 43 – Flash image window – Compare checksum and file size with original

Note: By default, the Keep settings and retain the current configuration box is checked. If you uncheck this box, the current configuration will be erased after the update.

WARNING: If you accidentally try to upload the wrong file format to the AC-MegaFi 2 device, a warning screen will be displayed (see example below) with the error message in orange: **“The uploaded image file does not contain a supported format. Make sure that you choose the generic image format for your platform ”**. If this happens, **STOP - DO NOT PROCEED**. Select **Cancel** to back out of this operation and avoid "bricking" your device.




Figure 44 – Flash image window – Image format check failure

Note: Updating from version 3.3.0 to version 3.4.1, or version 3.7.0 to version 3.8.0 there is a slightly different warning. In this case the size of the file is in question and the error message in yellow reads: **“It appears that you are trying to flash an image that does not fit into the flash memory, please verify the image file!”**. This is a known issue, and if the checksum value matches proceed by checking the box: **“Force upgrade: Select ‘Force upgrade’ to flash the image even if the image format check fails. Use only if you are sure that the firmware is correct and meant for your device!”**. Then proceed to the next step.




Figure 45 – Flash image window – Image size

8. Click on **Continue** on **Flash image?** only after the SHA256 values have been verified to match.
9. The **Flashing...** window will display.

WARNING: “Do not power off the unit until the image flashing is complete.”

Note: The update will take 3-5 minutes.



Figure 46 – Flashing window – message indicating progress of the system flashing process

10. When the image flash is complete, you will be taken back to the login page.
11. Log in to continue.

Notes: Current status may initially display **No Internet** and no signal strength bars. It will correct itself once the device properly boots up from the upgrade process.

Refresh the browser if the device has not gone back to the home screen after 10 minutes and re-login again.

12. Verify that the intended firmware upgrade successfully loaded by looking at the bottom right of any Mission Control page. Once verified, the firmware update is complete.



Figure 47 – Mission Control page showing Firmware Version


3.4 Backup Existing Configuration

If the user wants to backup an existing configuration, do the following in Mission Control:

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Save to File** button next to **Backup Existing Configuration**.

Note: By default, the **Omit System Passwords** is set – this will omit the admin password used by this specific device. If this backup configuration file is

loaded onto a different device, that device will keep using its own password. If the **Omit System Passwords** is not set, loading this backup configuration file will require using the admin password from the device which the file was obtained. This does not affect Wi-Fi passwords.



Admin Tools

System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Figure 48 – System Settings – Save to File button

3. A tar.gz (tarball) file is created and stored in Downloads. Take note of the date of the file for future reference if needed.
 - Selecting **Omit System Passwords** results in a backup file named:
backup-clean-Airgain-2026-05-27.tar
 - Unselecting **Omit System Passwords** results in a backup file named:
backup-Airgain-2026-05-27.tar




Figure 49 – Downloads folder showing downloaded tar.gz files

Note: The backup configuration file will **not** include the configured device password.

3.5 Load Configuration from File

If the user wants to load a backup/saved configuration (i.e., duplicate a configuration file onto other AC-MegaFi 2 devices or restore a previous configuration file), do the following in Mission Control:

Note: The backup configuration file will **not** bring over the previous device password if the **Omit System Password** setting was set (see previous section for more details). All other Wi-Fi settings, and configuration settings from that AC-MegaFi 2 device will be included.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Load File** button, sometimes referred to as **Upload archive...** next to **Load Configuration from File**.




Figure 50 – System Settings – Load File button

3. The **Uploading file...** window pop ups, select **Browse** to locate the appropriate tarball file and **Open**.



Figure 51 – Uploading file – Browse to locate file button




Figure 52 – Uploading file and Browse to and select the tarball file

- The **Uploading file...** pop-up window shows the file chosen to load. Verify it is the intended file before selecting **Upload** to continue with loading the file.



Figure 53 – Load Configuration from File – Uploading selected file

- In the **Apply backup?** pop up window, press **Continue** at the bottom to proceed with restoring the backup file and reboot. Otherwise, **Cancel** to abort the operation.




Figure 54 – Apply backup – Confirmation to continue


- Give the backup operation 3-5 minutes to finish as it reboots.

WARNING: Do not power off the device during this time.

3.6 Change Password

If the user requires to change the current password, do the following in Mission Control.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Change Password** button next to **Change Password**.



Admin Tools


System Settings

Primary SIM	physical SIM	▼
Physical SIM APN selection	Automatic	▼
LAN IP	192.168.113.1	
WAN/LAN Port Mode	WAN	▼
Update Firmware	Upload Firmware	
Backup Existing Configuration	Save to File	
Omit System Passwords	☐	
Load Configuration from File	Load File	
Change Password	Change Password	
Download Troubleshooting Files	Save to Archive	
Factory Defaults	Factory Defaults	
Vehicle Shutdown Delay	30 seconds	▼
Expert Configuration	Expert Configuration	
Reboot	Reboot	

Save & Apply ▼ **Save** **Reset**

Figure 55 – System Settings – Change Password button

3. The user is automatically put into Expert Configuration Mode and taken to the **System > Router Password** page.



Overview

Status

System

- Router Password
- Startup
- Scheduled Tasks
- Configuration
- GPS Configuration
- eSIM Manage
- VPN Configuration
- Remote Configuration

Network

Logout

Router Password **SSH Access** **SSH-Keys**

Router Password

Changes the administrator password for accessing the device

Password

Confirmation

Save

Figure 56 – Router Password page – Expert Configuration Mode

4. Enter a new password in the **Password** field and re-type it in the **Confirmation** field as well.

Note: The device will not accept weak passwords. Password must meet the following requirements: a minimum length of 10 characters and a randomized complexity of lowercase letters, uppercase letters, and numbers.




Figure 57 – Router Password page – Enter new password

5. Click on the **Save** button.
6. Once the change is confirmed by the device, the user will be put back in the Overview page.

3.7 Factory Defaults via Mission Control

If the user wants to return to factory default settings, the user can perform a factory reset to the AC-MegaFi 2 device in Mission Control as follows:

Note: Before proceeding with a factory reset, it is recommended to save a backup configuration of the device in case you need to revert to its previous settings. Follow the steps hi-lighted above in Section 3.4 Backup Existing Configuration.

Note: After a factory reset, AC-MegaFi 2's UUID may need to be reassigned for Cloud support. If cloud access breaks after a factory reset, contact the support team at connectivity.support@airgain.com for further assistance.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Factory Defaults** button next to **Factory Defaults**.




Figure 58 – System Settings – Factory Defaults button

3. A window will pop up and ask the user to confirm the operation. Click **OK** to continue.




Figure 59 – Confirmation to return settings back to factory defaults


4. Give the device 3-5 minutes to complete the operation.
5. Once the device recovers, the user will be asked to log in to Mission Control again.
6. The user will then be asked to accept the EULA agreement and change the default password.

To factory default the AC-MegaFi 2 using the **DISPLAY** button (in case of a forgotten password), press and hold the **DISPLAY** button for 20 seconds and release. The device will take a few minutes to recover, and all settings will now be set to factory default.

3.8 Vehicle Shutdown Delay

If the AC-MegaFi 2 device is installed in a vehicle, the user can increase the **Vehicle Shutdown Delay** setting up to 2 hours. The default setting is 30 seconds. This ensures that the AC-MegaFi 2 device will stay powered on after the vehicle is shut off and it will continue to provide services until the timer expires. To change this setting, do the following in Mission Control:

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click the drop-down arrow to expose the other pre-defined settings and select from **15 minutes**, **1 Hour**, or **2 Hours**.



The screenshot shows the 'Admin Tools' section with 'System Settings' expanded. The 'Vehicle Shutdown Delay' setting is highlighted with a red box, and its dropdown menu is open, showing options: '30 seconds', '30 seconds', '15 minutes', '1 hour', and '2 hours'. The '30 seconds' option is selected. At the bottom right, there are buttons for '& Apply', 'Save', and 'Reset'.


Figure 60 – System Settings – Vehicle Shutdown Delay options

3. Click on **Save & Apply** to confirm the new setting.

3.9 Reboot

If the user would like to reboot the AC-MegaFi 2, do the following in Mission Control.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Reboot** button.



Admin Tools


System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Save & Apply ▼ **Save** **Reset**

Figure 61 – System Settings – Reboot button

3. A pop-up window asks the user to confirm the operation. Click on **OK** to continue.



192.168.113.1 says

Do you really want to reboot now?

OK **Cancel**

Figure 62 – Confirmation message to reboot device

4. Wait for the device to reboot before continuing. The process will take 1 - 3 minutes.



Figure 63 – Message indicating device is being rebooted

5. The user will be asked to log in again into Mission Control after the device reboots. Click on the **To login...** button to do so.



Figure 64 – Prompt to log in after device reboots

3.10 Wireless Settings

Beginning with firmware version 3.4.1, two Guest Wi-Fi's or SSIDs have been introduced into Mission Control. There is one for 2.4 GHz and another for 5 GHz, for a total of 4 SSIDs that include the two primary SSIDs. Both Guest SSIDs are disabled by default while the two primary SSIDs are enabled by default.

 A screenshot of the "WiFi Settings" configuration page, divided into two sections: "WiFi 2.4Ghz Settings" and "WiFi 5Ghz Settings". Each section has a "Device Settings" header and a "Guest" section. In the 2.4Ghz section, the "WiFi 2.4Ghz Guest" section is highlighted with an orange box, showing "Radio Enabled" set to "Disabled". Similarly, in the 5Ghz section, the "WiFi 5Ghz Guest" section is highlighted with an orange box, also showing "Radio Enabled" set to "Disabled". Other settings include Channel (11 for 2.4Ghz, 157 for 5Ghz), Radio Enabled (Enabled), SSID (megafi-000632), Encryption (WPA2-PSK for 2.4Ghz, WPA3-SAE for 5Ghz), and a Key field. At the bottom right are buttons for "Save & Apply", "Save", and "Reset".


Figure 65 – System Settings – Expert Configuration button

To verify overall Wi-Fi settings, refer to Section 3.10.1 below. To modify the primary SSIDs, refer to Section 3.10.2. To enable and modify the Guest SSIDs, refer to Section 3.10.3.

3.10.1 Verify Wi-Fi Settings

To view current Wi-Fi settings, do the following:

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.



The screenshot shows the 'Admin Tools' section with a sub-header 'System Settings'. Below this, there is a list of settings and their corresponding controls:

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

At the bottom right, there are three buttons: 'Save & Apply', 'Save', and 'Reset'.

Figure 66 – System Settings – Expert Configuration button

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.




Figure 67 – Confirmation message to enter Expert Configuration mode

4. The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **Network > Wireless**.



Figure 68 – Navigation pane showing options available in Expert mode – Wireless

Note: To view the primary SSID hidden Keys/Passwords, click on the * (asterisk) button next to the **Key** field to make it visible for either SSID. By default, the key/password is the same for both 2.4 GHz and 5 GHz settings and printed on the label or on the LCD display screen.

WiFi 2.4Ghz Settings

Device Settings

Channel

11 (2462 MHz)

WiFi 2.4Ghz

Radio Enabled

Enabled

SSID

megafi-000632

Encryption

WPA2-PSK

Key

IZZcl84920

*

Hide SSID

WiFi 2.4Ghz Guest

Radio Enabled

Enabled

SSID

guest

Encryption

Disabled

Hide SSID

WiFi 5Ghz Settings

Device Settings

Channel

157 (5785 MHz)

WiFi 5Ghz

Radio Enabled

Enabled

SSID

megafi-000632

Encryption

WPA3-SAE

Key

IZZcl84920

*

Hide SSID

WiFi 5Ghz Guest

Radio Enabled

Disabled

Save & Apply

Save

Reset

Figure 69 – Wireless Settings – View hidden Keys

3.10.2 Change Wi-Fi Settings

The following options available for the primary WiFi 2.4GHz and 5 GHz Settings are:

Table 3 – Wi-Fi Settings for 2.4 GHz and 5 GHz

Wi-Fi Setting	WiFi 2.4 GHz Settings (Default)	WiFi 2.4 GHz Settings -Other Options	WiFi 5 GHz Settings (Default)	WiFi 5 GHz Settings -Other Options
Radio Enabled	Enabled	Disabled	Enabled	Disabled

Specifications are subject to change without notice. Copyright © 2026 All Rights Reserved. Registered Trademarks TM Airgain, Inc. Airgain, AirgainConnect, NimbeLink, and their associated logos are trademarks or registered trademarks of Airgain, Inc. Revised 07/02/26

51



Channel	11 (2462 Mhz)	Auto and Channels 1-11	157 (5785 Mhz)	Auto and Channels 36, 40, 44, 48, 149, 153, 157, 161
SSID	default SSID name on label or LCD Display screen		default SSID name on label or LCD Display screen	
Encryption	WPA2-PSK	WPA2-EAP, WPA3-EAP, WPA2-EAP/WPA3-EAP, WPA2-PSK/WPA3-SAE, WPA3-SAE, and Disabled	WPA3-SAE	WPA2-EAP, WPA3-EAP, WPA2-EAP/WPA3-EAP, WPA2-PSK/WPA3-SAE, WPA3-SAE, WPA2-PSK, and Disabled
Key	default key (password) on label or LCD Display screen		default key (password) on label or LCD Display screen	
Hide SSID – this will stop broadcasting the SSID, making it difficult for users to guess the WiFi name	Disabled	Enabled	Disabled	Enabled

To change current Wi-Fi settings, do the following:

Note: If you attempt to make wireless changes while connected to the device via Wi-Fi, expect to be disconnected after committing the changes. You will then have to reconnect to Wi-Fi using the new settings.

1. For settings with a drop-down menu arrow, such as **Radio Enabled**, click the arrow and choose the preferred setting from the options.

WiFi 2.4Ghz Settings

Device Settings

Channel
11 (2462 MHz)

WiFi 2.4Ghz

Radio Enabled

Enabled

SSID

Encryption

Key
IZZcl84920

Hide SSID
☐

WiFi 2.4Ghz Guest

Radio Enabled
Enabled

SSID
guest

Encryption
Disabled

Hide SSID
☐

WiFi 5Ghz Settings

Device Settings

Channel
157 (5785 MHz)

WiFi 5Ghz

Radio Enabled
Enabled

SSID
megafi-000632

Encryption
WPA3-SAE

Key
IZZcl84920

Hide SSID
☐

WiFi 5Ghz Guest

Radio Enabled
Disabled

Save & Apply
Save
Reset

Figure 70 – Wireless Settings – Selecting Drop-down Menu options

- For **SSID** and **Key** modifications, remove/delete or change the previous setting and enter the new **SSID** and/or new and appropriate **Key** (Must be at least 10 characters long) into their respective fields.

WiFi 2.4Ghz Settings

Device Settings

Channel11 (2462 MHz)

WiFi 2.4Ghz

Radio EnabledEnabled

SSIDnew-ssid

EncryptionWPA2-PSK

Keynewpassword

Hide SSID☐

WiFi 2.4Ghz Guest

Radio EnabledEnabled

SSIDguest

EncryptionDisabled

Hide SSID☐

WiFi 5Ghz Settings

Device Settings

Channel157 (5785 MHz)

WiFi 5Ghz

Radio EnabledEnabled

SSIDmegafi-000632

EncryptionWPA3-SAE

Key.....

Hide SSID☐

WiFi 5Ghz Guest

Radio EnabledDisabled

Save & Apply Save Reset

Figure 71 – Wireless Settings – Modifying SSID and Key fields

- Click on **Save** followed by **Save & Apply** to confirm the change(s).

Note: If the user selects either **WPA2-EAP** or **WPA3-EAP** encryption for **Wi-Fi 2.4** or **5 GHz** settings, the **Key** option goes away, and the user is presented with the following new options. Configure these settings as required for your Extensible Authentication Protocol (EAP) network environment.

- **RADIUS Server IP**
- **RADIUS Server Port**
 - Default setting - 1812
- **RADIUS Secret** - To view the hidden RADIUS Secret, click on the * (asterisk) button next to the field to make it visible for either SSID.

WiFi 2.4Ghz Settings

Device Settings

Channel11 (2462 MHz)

WiFi 2.4Ghz

Radio EnabledEnabled

SSIDmegafi-000632

EncryptionWPA2-EAP

RADIUS Server IP

RADIUS Server Port1812

RADIUS Secret

Hide SSID☐

WiFi 2.4Ghz Guest

Radio EnabledDisabled

WiFi 5Ghz Settings

Device Settings

Channel157 (5785 MHz)

WiFi 5Ghz

Radio EnabledEnabled

SSIDmegafi-000632

EncryptionWPA3-EAP

RADIUS Server IP

RADIUS Server Port1812

RADIUS Secret

Hide SSID☐

WiFi 5Ghz Guest

Radio EnabledDisabled

Save & Apply Save Reset

Figure 72 – Wireless Settings – EAP fields

Note: Devices that connect to either primary SSID will be assigned to IP addresses within the default LAN subnet of 192.168.113.x/24 or whatever was subsequently configured as described in Section 3.2 above.

3.10.3 Guest Wi-Fi Settings

The Guest Wi-Fi/SSIDs are disabled by default. The following options available for Guest Wi-Fi 2.4 GHz and 5 GHz settings are:

Table 4 – Guest Wi-Fi Settings for 2.4 GHz and 5 GHz

Guest Wi-Fi Setting	Guest WiFi 2.4 GHz Settings (Default)	Guest WiFi 2.4 GHz Settings -Other Options	Guest WiFi 5 GHz Settings (Default)	Guest WiFi 5 GHz Settings -Other Options
Radio Enabled	Disabled	Enabled	Disabled	Enabled
SSID	default SSID name is "guest"		default SSID name is "guest5G"	
Encryption	Disabled	WPA2-PSK, WPA2-EAP, WPA3-EAP, WPA2-EAP/WPA3-EAP, WPA2-PSK/WPA3-SAE, WPA3-SAE	Disabled	WPA2-PSK, WPA2-EAP, WPA3-EAP, WPA2-EAP/WPA3-EAP, WPA2-PSK/WPA3-SAE, WPA3-SAE
Key	none		none	
Hide SSID – this will stop broadcasting the SSID, making it difficult for users to guess the WiFi name	Disabled	Enabled	Disabled	Enabled

To change current Guest Wi-Fi settings, do the following:

Note: If you attempt to make Guest Wi-Fi changes while connected to the device via Guest Wi-Fi, expect to be disconnected after committing the changes. You will then have to reconnect to Wi-Fi using the new settings. Any device connected to a Guest Wi-Fi will not have access to MegaFi's Mission Control.

1. Enable the Guest Wi-Fi radio by selecting the Enabled option from the drop-down menu.

WiFi 2.4Ghz Settings

Device Settings

Channel11 (2462 MHz)

WiFi 2.4Ghz

Radio EnabledEnabled

SSIDmegafi-000632

EncryptionWPA2-PSK

Key.....*

Hide SSID☐

WiFi 2.4Ghz Guest

Radio EnabledEnabled

SSIDEnabled

EncryptionDisabled

Hide SSID☐

WiFi 5Ghz Settings

Device Settings

Channel157 (5785 MHz)

WiFi 5Ghz

Radio EnabledEnabled

SSIDmegafi-000632

EncryptionWPA3-SAE

Key.....*

Hide SSID☐

WiFi 5Ghz Guest

Radio EnabledEnabled

SSIDguest5G

EncryptionDisabled

Hide SSID☐

Save & Apply Save Reset

Figure 73 – Guest Wireless Settings – Selecting Drop-down Menu options

2. Change the Guest SSID as needed by typing it into the SSID field.
3. Change the Encryption as needed from the default setting of Disabled to any of the available options in the drop-down menu.
4. Enter an appropriate **Key** (Must be at least 10 characters long) into its field. Click on the * (asterisk) button next to the **Key** field to make it visible for either SSID.
5. Click on **Save** followed by **Save & Apply** to confirm the change(s).

Note: If the user selects either **WPA2-EAP** or **WPA3-EAP** encryption for **Wi-Fi 2.4** or **5 GHz** settings, the **Key** option goes away, and the user is presented with the following new options. Configure these settings as required for your

Extensible Authentication Protocol (EAP) network environment.

- **RADIUS Server IP**
- **RADIUS Server Port**
 - Default setting - 1812
- **RADIUS Secret** - To view the hidden RADIUS Secret, click on the * (asterisk) button next to the field to make it visible for either SSID.

WiFi 2.4Ghz Settings

Device Settings

Channel11 (2462 MHz)

WiFi 2.4Ghz

Radio EnabledEnabled

SSIDmegafi-000632

EncryptionWPA2-PSK

Key.....*

Hide SSID☐

WiFi 2.4Ghz Guest

Radio EnabledEnabled

SSIDguest

EncryptionWPA2-EAP

RADIUS Server IP

RADIUS Server Port1812

RADIUS Secret.....*

Hide SSID☐

WiFi 5Ghz Settings

Device Settings

Channel157 (5785 MHz)

WiFi 5Ghz

Radio EnabledEnabled

SSIDmegafi-000632

EncryptionWPA3-EAP

RADIUS Server IP

RADIUS Server Port1812

RADIUS Secret.....*

Hide SSID☐

WiFi 5Ghz Guest

Radio EnabledEnabled

SSIDguest5G

EncryptionDisabled

Hide SSID☐

Save & Apply Save Reset

Figure 74 – Guest Wireless Settings – EAP fields



Note: Devices that connect to either Guest SSID will be assigned to IP addresses within the subnet of 192.168.131.x/24 and are isolated from the main LAN subnet and from each other.

3.11 NAT vs. Passthrough Mode

The AC-MegaFi 2 device can be set to either NAT (default setting) or **Passthrough Mode**. In NAT Mode, the device acts as an intermediary between a local network and the internet, translating private IP addresses into a single public IP address. This helps enhance security by hiding internal devices from external networks and allows multiple devices to share a single public IP. **Passthrough Mode** disables **NAT** and typical router functions. In this mode, the MegaFi will simply act as a bridge and forwards traffic as-is, allowing a connected device (such as a firewall or router) to handle the carrier assigned IP assignments and manage the network. The carrier assigned IP address will be assigned to the device directly connected behind the AC-MegaFi 2 on the LAN 1 port, but the Subnet mask and Gateway can be modified as described below. In some cases, computers with specific software will require this IP and can be the recipient of the passed through IP address. In addition, setting the device to **Passthrough Mode** will disable the WAN/LAN2 port, Wi-Fi, Firewall, and IPsec VPN functions.

Prior to implementing **Passthrough Mode**, the user needs to take the following steps:


- **Connection to AC-MegaFi 2 Device** – the user will need to connect a computer workstation or laptop with an Ethernet cable to LAN port 1. The user will also need to make sure the computer is NOT connected to Wi-Fi.

Note: Only LAN port 1 is usable and all other LAN ports are disabled in **Passthrough Mode**.

- **Implement Custom APN/Static IP first** – Though not always the case, if the user is using a custom APN, the user will need to input the custom **APN** (Section 3.1) first prior to implementing **Passthrough Mode**. If the correct IP address does not appear on the device, please review SIM provisioning with the carrier. If the correct IP address does appear, then the user may proceed with implementing **Passthrough Mode** as instructed below.
- **Manually refresh the connected computer IP address** – Once in **Passthrough Mode**, the Mission Control software management interface will briefly be unreachable at <https://192.168.113.1> or whatever **LAN IP** address it has been configured to until the IP address is manually refreshed. If connection to Mission Control cannot be resolved after a couple of minutes, go to Step 11 below for options to try to regain connection to Mission Control.

To change between **NAT** and **Passthrough** modes, do the following in Mission Control:

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.



Admin Tools


System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Save & Apply Save Reset

Figure 75 – System Settings – Entering Expert Configuration mode

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.



192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

OK Cancel

Figure 76 – Confirmation message to enter Expert Configuration mode

- The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **System > Configuration**.





Figure 77 – Navigation pane showing options available in Expert mode – Configuration

- Under the **Networking** area, click on the drop-down arrow and select the desired mode: **NAT Mode** (default), or **Passthrough Mode** from the **Passthrough vs NAT (changing causes reboot)** option.



The screenshot shows the Configuration page with the following sections:

- Cloud**
 - UUID: E17EA7CE-0B45-4A74-BA57-1BA714A7A80
 - Cloud Poll URL: ei.nextivityinc.net
 - Cloud Poll Period (seconds): 60
 - Cloud Status URL:
 - Cloud Status: Connected (5/27/2026, 5:42:52 PM)
- Logging**
 - Logging Enabled: Logging Enabled
 - Push to Cloud: Push Enabled
 - Push to Cloud Period (seconds): 60
 - System Poll Period (seconds): 15
 - Show in Local UI: Local UI Enabled
- Networking** (highlighted with a red box)
 - Passthrough vs NAT (changing causes reboot)** (highlighted with a red box)
 - NAT Mode (selected)
 - Passthrough Mode
 - NAT Mode
 - LAN IP Address:
 - Client Isolation:

Figure 78 – AC-MegaFi 2 Configuration – Change modes (NAT or Passthrough)

6. A pop-up window will warn the user that temporary access to Mission Control will be lost after committing to the mode change. After committing to the mode change, the user will have the option to restore the default configuration by holding the **Reset** button for 30 seconds if they don't wish to continue with the mode change. Click **OK** to continue with the mode change.




Figure 79 – AC-MegaFi 2 Configuration – Change modes (NAT or Passthrough)

7. Selecting **Passthrough Mode** exposes **Subnet Selection Mode**. Select the desired **Subnet Selection Mode** from the dropdown menu (**Force 24 Subnet (Compatibility Mode)** or **Automatically Create Subnet**).

- **Force 24 Subnet (Compatibility Mode)** – this is the default selection. This selection forces a class C subnet (i.e. 255.255.255.0 or /24 in CIDR form) regardless of what the carrier has assigned. This will also use the first available IP address in the /24 block as the Gateway IP address.

Use case:

1. Only use this if the downstream device **cannot operate** with the carrier's native subnet. For example, downstream devices cannot handle small or non-standard WAN subnets like /31 or /30.
 2. Helpful in environments where firewalls insist on a /24 WAN network.
 3. This compatibility mode avoids issues where the carrier's assigned IP/mask combination:
 - falls into a non-usable network/broadcast range, or
 - results in overlapping networks at multiple sites.
- **Automatically Create Subnet** – This selection dynamically creates the subnet mask based on whatever subnet the carrier assigns to the modem. This also designates the server that assigned the IP address to the modem as the Gateway IP address.

Use case:

- Works best when the carrier assigns /31, /30, /29 or unusual subnet masks.
- Ensures IP Passthrough functions correctly without manual intervention.




Figure 80 – AC-MegaFi 2 Configuration – Subnet Selection Mode

8. Click on **Save & Apply** to confirm the change.

WARNING: Internet access, wireless connectivity and/or access to the AC-MegaFi 2 will become disrupted or unavailable after committing the mode change. Please allow 1-3 minutes for the configuration to apply.

9. Once Mission Control access is re-established, login again to Mission Control.
10. It is highly recommended to issue a **Reboot** (Section 3.9) to make sure the new setting takes hold. Please proceed with a **Reboot** at this time.
11. Once in **Passthrough Mode**, connect the desired device to LAN port 1. Give the MegaFi and the device a couple of minutes to properly reconfigure themselves. If the device does not properly obtain the expected IP address information, follow these added steps:
 - a. Power down both the AC-MegaFi 2 and the device connected to LAN port 1.
 - b. Verify that the Ethernet patch cable is properly interconnecting both the AC-MegaFi 2 via its LAN port 1 interface and the device's **WAN** port. If the device is another computer, it will be its Ethernet port.
 - c. Power up both devices.
 - d. Ensure that the connected device receives the appropriate IP address. Follow instructions from the device manufacturer to validate the IP address.
12. If connectivity becomes an issue to Mission Control, try one of the following actions to regain access to AC-MegaFi 2:

- a. Refresh the web browser to Mission Control.
- b. Connect an Ethernet cable to an enabled LAN port (LAN port 1 if in Passthrough mode) on the AC-MegaFi 2 and re-access Mission Control as usual through a web browser.
- c. Manually refresh connected computer IP address by opening a Windows PowerShell, or Command Prompt window on a PC with local access to AC-MegaFi 2 and enter the following commands at the prompt:
 - **ipconfig /release** <enter> - this will release the existing IP addresses




Figure 81 – Windows PowerShell window – `ipconfig /release` <enter>

- **ipconfig /renew** <enter> - this will refresh the IP addresses on the connected computer.




Figure 82 – Windows PowerShell window – `ipconfig /renew` <enter>

13. When changes have been completed, and to prevent any more setting changes, click on the **Logout** button to exit out of Mission Control and be taken back to the Log In page.




3.12 Band Lock, Band 1, Band 30, and Maximize Band 14 Settings

In certain situations, the user may need to **Band Lock** to Band 14 or 28. Also, **Band 1** and **Band 30** can be either enabled or disabled as needed depending on Mobile or Fixed setups. Finally, **Maximize Band 14 Usage** has been added to version 3.8.0. To make any changes to these features, do the following in Mission Control:

3.12.1 Band Lock Setting

Note: Before committing to this change, please make sure to validate that band 14 or 28 is available in your area as not all areas are equipped for band 14 or 28.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.



The screenshot shows the 'Admin Tools' section with a sub-header 'System Settings'. Below this, there is a list of settings and their corresponding controls:

- Primary SIM: physical SIM (dropdown)
- Physical SIM APN selection: Automatic (dropdown)
- LAN IP: 192.168.113.1 (text input)
- WAN/LAN Port Mode: WAN (dropdown)
- Update Firmware: Upload Firmware (button)
- Backup Existing Configuration: Save to File (button)
- Omit System Passwords: ☐ (checkbox)
- Load Configuration from File: Load File (button)
- Change Password: Change Password (button)
- Download Troubleshooting Files: Save to Archive (button)
- Factory Defaults: Factory Defaults (button)
- Vehicle Shutdown Delay: 30 seconds (dropdown)
- Expert Configuration: Expert Configuration (button, highlighted with an orange rectangle)**
- Reboot: Reboot (button)

At the bottom right, there are three buttons: 'Save & Apply' (with a dropdown arrow), 'Save', and 'Reset'.

Figure 83 – System Settings – Expert Configuration button

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.




Figure 84 – Confirmation to Enter Expert Configuration mode

4. The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **System > Configuration**.




Figure 85 – Navigation pane showing options available in Expert mode – Configuration

5. Under the **Other** area, use the drop-down arrow next to **Band Lock** to select **LTE B14 Only** or **LTE B28 Only**. Choose the **Default Band Configuration** option to set back to default setting in which the device relies on the Network to choose the appropriate band.




Figure 86 – Band Lock Setting


6. Click on **Save & Apply** to confirm the change.
7. When changes have been completed, and to prevent any more setting changes, click on the **Logout** button to exit out of Mission Control and be taken back to the Log In page.

3.12.2 Band 1 and Band 30 Settings

By default, **Band 1** is disabled (Mobile applications) and **Band 30** is enabled (Fixed applications).

To enable or disable these settings per your specific application, do the following in Mission Control:

1. These settings are located right below the Band Lock setting.



Other	
Hostname	Airgain
Reboot Offline Time (minutes)	Disabled
Band Lock	Default Band Configuration
Band 1	Disabled - Mobile applications
Band 30	Enabled - Fixed applications
Maximize Band 14 usage	Disable

Figure 87 – Band 1 and Band 30 Settings

2. Select the dropdown menu on either setting and select the opposite setting for either a Mobile or Fixed application.
3. Click on **Save & Apply** to confirm the change.
4. When changes have been completed, and to prevent any more setting changes, click on the **Logout** button to exit out of Mission Control and be taken back to the Log In page.

3.12.3 Maximize Band 14 Usage

Enabling this feature enforces Band 14-only operation under low-signal conditions for non-FirstNet AT&T SIMs. The service continuously monitors signal strength and reverts to the standard band-selection logic once signal quality meets the threshold. Additionally, a daily forced network scan has been added for stationary devices to ensure optimal connectivity.

By default, this setting is disabled. To enable this setting, do the following in Mission Control:

1. This setting is located right below the Band Lock and Band 1 and 30 settings.

Other	
Hostname	Airgain
Reboot Offline Time (minutes)	Disabled
Band Lock	Default Band Configuration
Band 1	Disabled - Mobile applications
Band 30	Enabled - Fixed applications
Maximize Band 14 usage	Disable


Figure 89 – Maximize Band 14 usage Setting

2. Select the drop-down menu and select Enable.
3. Click on **Save & Apply** to confirm the change.
4. When changes have been completed, and to prevent any more setting changes, click on the **Logout** button to exit out of Mission Control and be taken back to the Log In page.

3.13 SSH Access

The user-enabled SSH instance (Dropbear) offers SSH network shell access and an integrated SCP server. Access to SSH on the AC-MegaFi 2 is turned off by default. To enable command line **SSH Access** to the device, do the following in Mission Control.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.



Admin Tools


System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

[Save & Apply](#) [Save](#) [Reset](#)

Figure 90 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Mode. Click **OK** to continue.



192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

[OK](#) [Cancel](#)

Figure 91 – Confirmation to Enter Expert Configuration mode

4. The left-pane menu exposes pages only available in Expert Mode. Navigate to **System > Router Password > SSH Access**.

Router Password **SSH Access** SSH-Keys

SSH Access

Dropbear offers SSH network shell access and an integrated SCP server

Dropbear Instance

This section contains no values yet

Add Instance

Save & Apply Save Reset

Figure 92 – SSH Access – add new instance

5. Click on the **Add instance** button.
6. The Interface field will be pre-populated with the **LAN** interface by default and is the only option when needing local access to the device. The other options in the dropdown menu are **wan**, **wan6**, and **wwan** when remote **SSH Access** is required.
7. In the **Port** field, change the port number from the default **2022** to **22** (well-known SSH port for local access) or another port of your choosing that is not being used and hard for hackers to guess (typical for SSH wan access).
8. **Idle Timeout** is set to **300** seconds by default. Adjust for more or less time in seconds as needed.
9. All other settings are not required and are optional.
10. Click on **Save & Apply** to confirm changes.

SSH Access

Dropbear offers SSH network shell access and an integrated SCP server

Dropbear Instance

Interface lan: Delete

Listen only on the given interface or, if unspecified, on all

Port 22

Password authentication ☒ Allow SSH password authentication

Allow root logins with password ☒ Allow the root user to login with password

Gateway Ports ☐ Allow remote hosts to connect to local SSH forwarded ports

Idle Timeout 300

Add Instance

Save & Apply Save Reset

Figure 93 – SSH Access – Change port number from 2022 to 22

11. Use your preferred SSH client to access AC-MegaFi 2 on port **22** or whatever port configured and use root as the username along with the current router

password.

Note: The SSH password will be the same as the Router Password.

12. **Optional:** If remote **SSH Access** to the device is required and the device has a custom static/public IP address, do the following to open the appropriate **wan** interface:
 - a. Within the **SSH Access** page, click on **Add instance**.
 - b. Choose the appropriate wan interface from the **Interface** drop-down menu.
 - **wwan** – most typical choice to access SSH from the cellular network
 - **wan** – only select if the device has internet connection through wan port
 - **wan6** – currently not widely used
 - c. Choose a port such as 46556 or something similar that is not the typical SSH port 22.
 - d. It is recommended to leave the **Idle Timeout** set to **300** or less for **wan** access for security reasons.
 - e. All other settings are not required and are optional.
 - f. Click on **Save & Apply** to confirm changes.

3.14 GPS Output Configuration

This is where the user can configure GPS settings on AC-MegaFi 2 for a **GPS Server**, **GPS Internal Reporting**, and **GPS Output** in Mission Control.

- **GPS Server** – This option provides GPS data to applications or clients that request it using a predefined server port.
- **GPS Internal Reporting** – This is how the AC-MegaFi 2 will process GPS data and display it on-device only. The user can choose the format and the optional NMEA station code or TAIP ID and Rate. The default format setting is NMEA.
- **GPS Output** – This most widely used option transmits or shares GPS data to other systems using a host's IP address, a port number, a defined format (NMEA or TAIP), and a TCP/IP connection method using UDP as the protocol of choice. NMEA station code or TAIP ID and Rate are other options available in this area.

GPS Output Configuration

Configure GPS output in NMEA and TAIP format to hosts

GPS Server

Server Port

GPS Internal Reporting

Output Format

NMEA

Specify NMEA or TAIP output

NMEA station code or TAIP ID

Rate

1

Optional rate limit in seconds

GPS Output

This section contains no values yet

Add output

Save & Apply

Save

Reset

Figure 94 – GPS Output Configuration page

3.14.1 GPS Server

To set up the AC-MegaFi 2 to act like a **GPS Server** where GPS clients can request GPS data from, do the following in Mission Control.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.

Admin Tools

System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Save & Apply | **Save** | **Reset**

Figure 95 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.

192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

OK | **Cancel**

Figure 96 – Confirmation to Enter Expert Configuration mode

4. The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **System > GPS Configuration > GPS Server**.
5. Enter the designated server port number for the **GPS Server** in the **Server Port** field, followed by hitting the Enter button. We entered **21000** in our example below:

GPS Output Configuration

Configure GPS output in NMEA and TAIP format to hosts

GPS Server

Server Port

GPS Internal Reporting

Output Format

Specify NMEA or TAIP output

NMEA station code or TAIP ID

Rate

Optional rate limit in seconds

GPS Output

This section contains no values yet

Add output

Save & Apply

Save

Reset

Figure 97 – GPS Server Port Configuration

- Click on **Save & Apply** to confirm the **GPS Server** setting.

3.14.2 GPS Internal Reporting

This section modifies the **GPS Internal Reporting** format and how it is displayed on AC-MegaFi 2. To modify these settings, do the following in Mission Control.

- Navigate to **Overview > System Settings** under **Admin Tools**.
- Click on the **Expert Configuration** button to enter Expert Configuration mode.

Admin Tools

System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

[Save & Apply](#) | [Save](#) | [Reset](#)

Figure 98 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.


192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

[OK](#) | [Cancel](#)

Figure 99 – Confirmation to Enter Expert Configuration mode

4. The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **System > GPS Configuration > GPS Internal Reporting**.



GPS Output Configuration

Configure GPS output in NMEA and TAIP format to hosts

GPS Server

Server Port

GPS Internal Reporting

Output Format: NMEA
Specify NMEA or TAIP output

NMEA station code or TAIP ID

Rate: 1
Optional rate limit in seconds

GPS Output

This section contains no values yet

Add output

Save & Apply Save Reset

Figure 100 – GPS Internal Reporting Configuration

5. **NMEA** is the default output format. Modify the following as needed for the AC-MegaFi 2 to display the GPS message on-device.
 - a. **Output Format** – TAIP or NMEA
 - b. **NMEA station code or TAIP ID** (optional) – enter a valid alphanumeric value that is 4 characters long.
 - c. **Rate** (optional) – this parameter is in seconds. Leave as is or enter a rate between 1 – 3600.
6. Click on **Save & Apply** to confirm the **GPS Internal Reporting** settings.
7. To verify the on-device GPS settings, navigate to **Overview > System Settings** under **Admin Tools**.
8. Click on the **Expert Configuration** button to enter Expert Configuration mode.
9. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.
10. The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **Status > Modem Status** and verify the GPS as shown below for either **NMEA** or **TAIP** format.

Modem Status			
System Name	MegaFi_2	LTE Connection state	Connected
Modem Software Version	MOR:160005 POR:100413 AOR:001151 COR:150123	Signal Percentage	100%
IMEI	359172391063678	TX Bytes	48371643
ICCID	89011004330217191434	RX Bytes	49925165
IMSI	313100021722439	TX Packets	118649
Phone Number		RX Packets	108739
Latitude	32.720509		
Longitude	-117.036964		
NMEA/TAIP Position	\$GPGGA,010114.000,3243.23039,N,11702.21759,W,1,12,0.8,140.9,M,-35.0,M,,5150*66		
GPS UTC Timestamp	Wed May 27 2026 18:01:15 GMT-0700 (Pacific Daylight Time)		
Mode	5G+	APN	firstnet-broadband
ID	80648624	Band	14
PID	184	TAC	33540
EARFCN	5330	RSRP	-87 dBm
Home Network MCC	313	RSRQ	-9 dB
Home Network MNC	100	RSSI	-61 dBm
Home Network Name	FirstNet	SINR	9.4 dB
		TX Power	7 dBm

Figure 101 – On-device GPS NMEA message format


Modem Status			
System Name	MegaFi_2	LTE Connection state	Connected
Modem Software Version	MOR:160005 POR:100413 AOR:001151 COR:150123	Signal Percentage	100%
IMEI	359172391063678	TX Bytes	46317896
ICCID	89011004330217191434	RX Bytes	49364930
IMSI	313100021722439	TX Packets	116182
Phone Number		RX Packets	106998
Latitude	32.720509		
Longitude	-117.036964		
NMEA/TAIP Position	>RPV03575+3272050-1170369600015432;ID=5150;*7E<		
GPS UTC Timestamp	Wed May 27 2026 17:59:36 GMT-0700 (Pacific Daylight Time)		
Mode	5G+	APN	firstnet-broadband
ID	80648624	Band	14
PID	184	TAC	33540
EARFCN	5330	RSRP	-87 dBm
Home Network MCC	313	RSRQ	-10 dB
Home Network MNC	100	RSSI	-56 dBm
Home Network Name	FirstNet	SINR	4.8 dB
		TX Power	5 dBm

Figure 102 – On-device GPS TAIP message format

3.14.3 GPS Output

This section will enable the AC-MegaFi 2 to transmit or share GPS data to a single or multiple hosts running a GPS receiver or listener. Do the following to configure **GPS Output** in Mission Control.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.



The screenshot shows the 'Admin Tools' section with a sub-header 'System Settings'. Below this, there is a list of settings and their corresponding controls:

- Primary SIM: physical SIM (dropdown)
- Physical SIM APN selection: Automatic (dropdown)
- LAN IP: 192.168.113.1 (text input)
- WAN/LAN Port Mode: WAN (dropdown)
- Update Firmware: Upload Firmware (button)
- Backup Existing Configuration: Save to File (button)
- Omit System Passwords: ☐ (checkbox)
- Load Configuration from File: Load File (button)
- Change Password: Change Password (button)
- Download Troubleshooting Files: Save to Archive (button)
- Factory Defaults: Factory Defaults (button)
- Vehicle Shutdown Delay: 30 seconds (dropdown)
- Expert Configuration**: **Expert Configuration** (button, highlighted with an orange rectangle)
- Reboot: Reboot (button)

At the bottom right, there are three buttons: 'Save & Apply' (with a dropdown arrow), 'Save', and 'Reset'.

Figure 103 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.




Figure 104 – Confirmation to Enter Expert Configuration mode

4. The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **System > GPS Configuration > GPS Output**.





Figure 105 – GPS Output Configuration – Add output

5. Select **Add output** and enter the following information:
 - **Host IP Address** – Enter the IP address of the workstation or laptop computer running a GPS client. Or select Broadcast to LAN for multiple locally connected devices that need to simultaneously receive GPS information.
 - **Port** – can be any network port number from 1024 on, as long as it is not blocked and not already in use (stay away from well-known port numbers in the range between 0-1023)
 - **Output Format** – TAIP or NMEA
 - **NMEA station code or TAIP ID** (optional) – enter a valid alphanumeric value that is 4 characters long.

- **TCP/UDP** – UDP is typically the most widely used option. Check with your device to ensure what protocol it is set to.
- **Rate** – this parameter is in seconds. Leave as is or enter a rate between 1 – 3600.

Note: In some cases, and for certain systems to receive the proper GPS data, it is best practice to enter a value of 1 in this field or the matching rate value set on the GPS receiver.



The screenshot shows the 'GPS Output' configuration window. It contains the following fields and controls:

- Host IP Address:** Text input field with value '192.168.113.104'.
- Port:** Text input field with value '5555'.
- Output Format:** Dropdown menu with 'TAIP' selected.
- Specify NMEA or TAIP output:** Text input field with value '1755'.
- TCP/UDP:** Dropdown menu with 'UDP' selected.
- Rate:** Text input field with value '1'.
- Optional rate limit in seconds:** Text below the Rate field.
- Buttons:** 'Delete' (top right), 'Add output' (bottom left), 'Save & Apply' (bottom right, highlighted), 'Save' (bottom right), and 'Reset' (bottom right).

Figure 106 – GPS Output Configuration – Values for adding new output

6. Click on **Save & Apply** to confirm the GPS Output settings.
7. When changes have been completed, and to prevent any more setting changes, click on the **Logout** button to exit out of Mission Control and be taken back to the Log In page.

Note: Multiple outputs can be added and configured to transmit and share GPS data to individual clients. This is helpful if you use distinct port numbers, etc. Just repeat this process as needed. Otherwise, select Broadcast to LAN in the Host IP Address drop-down menu to send GPS information to multiple hosts using the same port number, etc. This is especially helpful when you do not know what IP address a host(s) will get assigned from the DHCP server.

Note: There is a **Delete** button to the top right of the **GPS Output**. If the output is no longer needed, click on the button to delete it followed by clicking on **Save & Apply**.

3.15 WAN/LAN Port Mode

The AC-MegaFi 2 has two physical Ethernet ports. By default, the left port labeled **WAN/LAN2** is set to WAN mode. It can be set to function as a second LAN port if desired. To change the port mode on this port, do the following in Mission Control.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the drop-down menu next to **WAN/LAN Port Mode** and select **LAN**.




Figure 107 – WAN/LAN Port Mode options

3. Click on **Save & Apply** to confirm the **WAN/LAN Port Mode** setting.

Note: The AC-MegaFi 2 is capable of receiving PoE (Power over Ethernet) through the **WAN/LAN2** port. Check the AC-MegaFi 2 User Manual for specifications.

3.16 LCD Configuration

The AC-MegaFi 2 LCD display screen can be configured for the following settings:


Table 5 – LCD Screen Settings

LCD Setting	Fixed and Mobile Kit LCD Settings (Default)	LCD Settings - Other Options	MegaGo 2 LCD Settings (Default)
Screen Orientation	Portrait	Landscape	Landscape
Detail Level	Full	Minimal	Full
Turn off screen after (seconds)	600	Always On, custom (-1 – 3600)	Always On

Switch screen information (seconds)	15	1-60	15
Show Mission Control Password on the Display	Disabled	Enabled	Disabled

To make any changes to the LCD Display screen, do the following in Mission Control.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.



Admin Tools

System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

[Save & Apply](#) [Save](#) [Reset](#)

Figure 108– System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.




Figure 109 – Confirmation to Enter Expert Configuration mode

4. The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **System > Configuration > LCD Configuration**.

LCD Configuration	
Screen Orientation	Portrait ▼
Detail Level	Full ▼
Turn off screen after (seconds)	600 ▼
Switch screen information (seconds)	15
Show Mission Control Password on the Display	Disabled ▼

Figure 110 – LCD Configuration – default settings

5. For settings with a drop-down menu arrow, click the arrow and choose the preferred setting.
 - **Screen Orientation** – select from Portrait (default) or Landscape
 - **Detail Level** – select from Full (default) or Minimal
 - **Turn off screen after (seconds)** – select from 600 (default), Always on, or enter a custom value in seconds between -1 and 3600.
 - **Show Mission Control Password on the Display** – Beginning in firmware release version 3.4.1, changing the default password enables this feature and no longer displays the password on the display screen. Select from **Disabled** (default) or **Enabled** to display the device password on the display screen.
6. To modify **Switch screen information (seconds)**, remove or delete the previous setting (default is set to 15) and enter a new setting between 1 and 60 in this field, and hit **Enter**. Otherwise, it will revert back to its default setting, or pre-configured setting.
7. Click on **Save & Apply** to confirm the change(s).

3.17 SNMP

Beginning with firmware release version 3.4.1, SNMP was implemented into Mission Control. Though it is currently in an experimental feature. Please use this section with caution. To configure SNMP settings, do the following in Mission Control:

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.




Figure 111 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.




Figure 112 – Confirmation to Enter Expert Configuration mode

- The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **Network > SNMP**.





Figure 113 – Navigation pane showing options available in Expert mode – Configuration

- The following SNMP fields are available.
 - Service Enabled** – select from **Disabled** (default) or Enabled from the drop-down menu
 - User** – the default username is “**airgain123**”. Change the username as needed for your environment
 - Authentication Protocol** – select from **SHA-512** (default), **MD5**, **SHA-1**, **SHA-224**, **SHA256**, **SHA-384** from the drop-down menu.
 - Encryption Protocol** – select from **AES-256** (default), **DES**, **AES-128**, **AES-192**
 - Authentication Password** – set to “**authpassword123**” by default. Change the authentication password as needed for your environment.
 - Encryption Password** - set to “**privpassword123**” by default. Change the encryption password as needed for your environment.



The image shows the 'SNMP Settings (Experimental Feature)' form. It contains the following fields and options:

SNMP Settings (Experimental Feature)	
Service Enabled	Disabled
User	airgain123
Authentication Protocol	SHA-512
Encryption Protocol	AES-256
Authentication Password	
Encryption Password	


At the bottom right, there are three buttons: 'Save & Apply', 'Save', and 'Reset'.

Figure 114 – SNMP Settings

3.18 Client Isolation

Beginning with firmware release version 3.4.1, Client Isolation was implemented and enabled by default on both the main LAN subnet and Guest SSIDs. This feature in effect isolates client devices in which they cannot reach or communicate with each other within their respective network. To disable Client isolation for the main LAN subnet and let client devices reach or communicate with each other, do the following in Mission Control:

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.



The screenshot shows the 'Admin Tools' section with a sub-header 'System Settings'. Below this, there is a list of configuration options and their corresponding controls:

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

At the bottom right, there are three buttons: 'Save & Apply', 'Save', and 'Reset'.

Figure 115 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.




Figure 116 – Confirmation to Enter Expert Configuration mode

4. The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **System > Configuration**.




Figure 117 – Navigation pane showing options available in Expert mode – Configuration

5. Select **Disabled** from the drop-down menu to Disable Client isolation.




Figure 118 – Client Isolation

- Click on **Save & Apply** at the bottom to confirm the change.


3.19 Failover Primary Connection

Failover Primary Connection is set to **WAN – Internet Connection** by default. If you have both a WAN and WWAN connection, the physical WAN connection will be the preferred connection in this setting. If WAN connection is lost, the device will failover to the WWAN interface or cellular modem connection (**WWAN – Modem Connection**). With version 3.8.0, other settings were added to enhance Failover connections.

If you prefer the WWAN interface to be your primary connection, do the following in Mission Control:

Note: If you are only using the WWAN connection (most typical setup), there is no configuration needed and this setting can be left at default setting.

- Navigate to **Overview > System Settings** under **Admin Tools**.
- Click on the **Expert Configuration** button to enter Expert Configuration mode.



Admin Tools

System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Save & Apply
Save
Reset

Figure 119 – System Settings – Expert Configuration

- A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.




Figure 120 – Confirmation to Enter Expert Configuration mode

4. The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **System > Configuration**.




Figure 121 – Navigation pane showing options available in Expert mode – Configuration

5. Scroll down to **Other** section and select **WWAN – Modem Connection** from the drop-down menu for **Failover Primary Connection**.

Other

Hostname
Reboot Offline Time (minutes)
Band Lock
Band 1
Band 30
Maximize Band 14 usage
Failover Primary Connection
Failover Switch Time (seconds)
dB Threshold as Failover Criteria
dB Threshold Value
dB Hysteresis Value
Purge eSIM profiles if Factory Defaults
Sensors Temperature Unit
Restore Configuration

Airgain
Disabled
Default Band Configuration
Disabled - Mobile applications
Enabled - Fixed applications
Disable
WAN - Internet Connection
WAN - Internet Connection
WWAN - Modem Connection
-120
10
Disabled
Fahrenheit
Factory Defaults

Figure 122 – Failover Primary Connection

- Consider the following Failover feature enhancements and set them as needed. These settings are as follows:

Table 6 – Failover Settings

Failover Setting	Default setting	Range or Other Options	Description
Failover Switch Time (seconds)	15	Values between 5 and 180. Value must be a multiple of 5.	This is the amount of time the device will wait before failing over after detecting an interface failure. An added amount of time can be expected due to internal health-polling checks that can vary between 5 to 90 seconds.
dB Threshold as Failover Criteria	Disabled	Enabled	If enabled, the following two dB Threshold and Hysteresis values will be considered.
dB Threshold Value	-120	Values between -140 and -80	This value is related to the modem RSRP value. Where > -90 dB is excellent and < -120 dB is poor.
dB Hysteresis Value	10	Values between 0 and 40	This setting is to prevent rapid switching (ping-pong) when the signal level fluctuates around the threshold value. Hysteresis adds a margin (offset) so the UE doesn't react to tiny fluctuations near that value.

Other	
Hostname	Airgain
Reboot Offline Time (minutes)	Disabled
Band Lock	Default Band Configuration
Band 1	Disabled - Mobile applications
Band 30	Enabled - Fixed applications
Maximize Band 14 usage	Disable
Failover Primary Connection	WWAN - Modem Connection
Failover Switch Time (seconds)	15
dB Threshold as Failover Criteria	Disabled
dB Threshold Value	-120
dB Hysteresis Value	10

Figure 123 – Failover Switch Time and dB Threshold and Hysteresis Settings

- Click on **Save & Apply** at the bottom to confirm the changes.

3.20 Network Scan

The AC-MegaFi 2 is now capable of producing a manual scan list of available bands. A Network Scan menu page has been added to Mission Control under Expert Configuration / Status that enables the user to scan for available bands and export the result. To produce a manual scan, do the following in Mission Control:

- Navigate to **Overview > System Settings** under **Admin Tools**.
- Click on the **Expert Configuration** button to enter Expert Configuration mode.

Admin Tools

System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	<button>Upload Firmware</button>
Backup Existing Configuration	<button>Save to File</button>
Omit System Passwords	☐
Load Configuration from File	<button>Load File</button>
Change Password	<button>Change Password</button>
Download Troubleshooting Files	<button>Save to Archive</button>
Factory Defaults	<button>Factory Defaults</button>
Vehicle Shutdown Delay	30 seconds
Expert Configuration	<button>Expert Configuration</button>
Reboot	<button>Reboot</button>

Save & Apply Save Reset

Figure 124 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click OK to continue.

192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

OK Cancel

Figure 125 – Confirmation to Enter Expert Configuration mode

4. The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **Status > Network Scan**.
5. Click on the **Scan Now** button to produce a list of available bands.




Figure 126 – Network Scan

- After the scan is complete, the results can be exported by clicking on the **Export Results**.

4G (LTE)										
EARFCN	RXLEV	MCC	MNC	CellID	CellStatus	TAC	PCI	RSRP	RSRQ	BW
5330	-62	313	100	79474863	Suitable	33547	388	-91	-12	10
700	-44	310	410	79474696	Suitable	33547	19	-75	-11	20
5110	-60	310	410	79474703	Suitable	33547	321	-83	-6	10
66686	-57	310	410	79474710	Suitable	33547	366	-91	-17	10
9820	-59	310	410	79474837	Suitable	33547	275	-92	-16	10
66986	-74	310	410	79474870	Suitable	33547	488	-98	-7	10
66536	-59	310	260	226809090	Suitable	12101	-	-88	-9	20
66911	-78	311	480	90670097	Suitable	13827	321	-104	-12	5
66811	-63	311	480	90734604	Suitable	13827	283	-102	-20	15
1000	-52	311	480	90734606	Suitable	13827	283	-85	-16	10
68611	-67	310	260	226809405	Suitable	12101	-	-93	-12	5
5035	-61	310	260	226809365	Suitable	12101	426	-89	-14	5
875	-52	310	260	226809099	Suitable	12101	426	-86	-15	15
2560	-61	311	480	13934611	Suitable	13827	283	-93	-15	10

Figure 127 – Export Results

- A csv file will be generated automatically saved to your local computer.

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q
1	4G (LTE)																
2	EARFCN	RXLEV	MCC	MNC	CellID	CellStatus	TAC	PCI	RSRP	RSRQ	BW						
3	5330	-62	313	100	79474863	Suitable	33547	388	-91	-12	10						
4	700	-44	310	410	79474696	Suitable	33547	19	-75	-11	20						
5	5110	-60	310	410	79474703	Suitable	33547	321	-83	-6	10						
6	66686	-57	310	410	79474710	Suitable	33547	366	-91	-17	10						
7	9820	-59	310	410	79474837	Suitable	33547	275	-92	-16	10						
8	66986	-74	310	410	79474870	Suitable	33547	488	-98	-7	10						
9	66536	-59	310	260	2.27E+08	Suitable	12101		-88	-9	20						
10	66911	-78	311	480	90670097	Suitable	13827	321	-104	-12	5						
11	66811	-63	311	480	90734604	Suitable	13827	283	-102	-20	15						
12	1000	-52	311	480	90734606	Suitable	13827	283	-85	-16	10						
13	68611	-67	310	260	2.27E+08	Suitable	12101		-93	-12	5						
14	5035	-61	310	260	2.27E+08	Suitable	12101	426	-89	-14	5						
15	875	-52	310	260	2.27E+08	Suitable	12101	426	-86	-15	15						
16	2560	-61	311	480	13934611	Suitable	13827	283	-93	-15	10						

Figure 128 – scan results csv file

3.21 IPsec VPN

The AC-MegaFi 2 device can now serve as an endpoint for an IPsec VPN tunnel. Within Mission Control, a VPN Configuration menu page has been added within Expert Configuration. To configure a VPN tunnel, do the following in Mission Control.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.

Admin Tools

System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Save & Apply **Save** **Reset**

Figure 129 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.

192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

OK **Cancel**

Figure 130 – Confirmation to Enter Expert Configuration mode

4. The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **System > VPN Configuration**.

Warning: You must specify at least one authentication method: PSK, EAP, or certificate [Dismiss](#)

Warning: You must specify a server name [Dismiss](#)

Overview

Status

System

Router Password

Startup

Scheduled Tasks

Configuration

GPS Configuration

eSIM Manage

VPN Configuration

Network

Logout

VPN Configuration

Set up the VPN server details and connection parameters

Server name

VPN Type

Client certificate [Browse...](#)

CA certificate [Browse...](#)

PSK (Pre-Shared Key) [*](#)

Username

Password [*](#)

Autostart VPN ☐

[Save & Connect](#) [Save](#) [Reset](#)

Figure 131 – VPN Configuration

Note: The warnings at the top will disappear as you configure and commit the necessary parameters.

Note: Depending on the VPN Server setup, the following may or may not be needed in order to configure the VPN tunnel and both sides should match up. Relevant certificate files and parameters will be given to you by your VPN server administrator.

- **Server name** – URL or IP address the VPN server (required)
- **VPN Type** – choose either IKEv1 or IKEv2 from the drop-down menu (required)
- **Client certificate** – browse your local computer to find and upload the file
- **CA certificate** - browse your local computer to find and upload the file
- **PSK (Pre-Shared Key)** – enter the pre-shared key (click on the asterisk icon to the right to unhide the key)
- **Username** and **Password** – enter the username and password (click on the asterisk icon to the right to unhide the password)
- **Autostart VPN** – check the box if the VPN tunnel should automatically start upon reboot or restart
- **Save & Connect** or **Apply unchecked** – select **Save & Connect** to save the configuration and connect right away or select **Apply unchecked** once to pause full settings commit and press a second time to fully apply settings and commit from the drop-down menu
- **Save** – save current settings but do not fully apply or confirm the settings
- **Reset** – clear settings that have not been applied

- In the example below, the VPN server administrator configured the VPN server such that the tunnel requires to be type IKEv2, both a client and CA certificates is required, as well as a pre-shared key, and user account credentials.

VPN Configuration

Set up the VPN server details and connection parameters

Server name: vpn.server.url

VPN Type: IKEv2

Client certificate: /etc/swanctl/x509/client.crt

CA certificate: /etc/swanctl/x509ca/ca.crt

PSK (Pre-Shared Key): [Redacted]

Username: user

Password: [Redacted]

Autostart VPN: ☐

Buttons: Save & Connect, Save, Reset

Figure 132 – VPN Configuration - Settings

- If **Save & Connect** is selected, the VPN tunnel will begin to connect and the status of the connection will be shown at the top (**VPN Status** – either **Disconnected**, **Connecting to ...** or **Connected to ...**).

VPN Configuration

Set up the VPN server details and connection parameters

VPN Status: Disconnected

Disconnect VPN: [Disconnect]

Figure 133 – VPN Status – Disconnected

VPN Configuration

Set up the VPN server details and connection parameters

VPN Status: Connecting to vpn.strong2.nextivity.cloud

Disconnect VPN: [Disconnect]

Figure 134 – VPN Status – Connecting to...

VPN Configuration

Set up the VPN server details and connection parameters

VPN Status: Connected to vpn.strong2.nextivity.cloud

Disconnect VPN: [Disconnect]

Figure 135 – VPN Status – Connected

Note: If the connection is not successful, please contact your VPN server administrator to confirm the certificates and settings.

- Click the **Disconnect** button to stop and disconnect the VPN tunnel.



Figure 136 – Disconnect VPN

3.22 Modify Hostname

By default, the AC-MegaFi 2 device is configured with the hostname of Airgain. To modify the hostname, do the following in Mission Control.

- Navigate to **Overview > System Settings** under **Admin Tools**.
- Click on the **Expert Configuration** button to enter Expert Configuration mode.




Figure 137 – System Settings – Expert Configuration

- A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.




Figure 138 – Confirmation to Enter Expert Configuration mode

- The landing page is **Status > General**. The current Hostname of the device is listed at the top.

General	
• System	
Hostname	Airgain
Model	MediaTek MT7981 RFB
Architecture	ARMv8 Processor rev 4
Target Platform	mediatek/filogic
Firmware Version	OpenWrt 23.05.5 r24106-10cc5fcd00 / MegaFi 2 v3.7.0.21
Kernel Version	5.15.167
Local Time	2026-06-01 18:59:11
Uptime	0h 4m 52s
Load Average	0.60, 0.66, 0.33

Figure 139 – Status General - Hostname of the device

- Now navigate to **System > Configuration**.





Figure 140 – Navigation pane showing options available in Expert mode – Configuration


6. Towards the bottom of this page, in the **Other** section, the current **Hostname** configured is shown.



Other	
Hostname	Airgain
Reboot Offline Time (minutes)	Disabled
Band Lock	Default Band Configuration
Band 1	Disabled - Mobile applications
Band 30	Enabled - Fixed applications
Maximize Band 14 usage	Disable
Failover Primary Connection	WAN - Internet Connection

Figure 141 – Other – Hostname


7. To change the **Hostname** of the device, type over the current hostname and click on **Save & Apply** at the bottom.



Other	
Hostname	NewHostName
Reboot Offline Time (minutes)	Disabled
Band Lock	Default Band Configuration
Band 1	Disabled - Mobile applications
Band 30	Enabled - Fixed applications
Maximize Band 14 usage	Disable
Failover Primary Connection	WAN - Internet Connection

Figure 142 – Other – New Hostname

8. Navigate back to **Status > General** to verify the new hostname.



General	
• System	
Hostname	NewHostName
Model	MediaTek MT7981 RFB
Architecture	ARMv8 Processor rev 4
Target Platform	mediatek/filogic
Firmware Version	OpenWrt 23.05.5 r24106-10cc5fcd00 / MegaFi 2 v3.7.0.21
Kernel Version	5.15.167
Local Time	2026-06-01 19:05:26
Uptime	0h 11m 7s
Load Average	0.75, 0.52, 0.36

Figure 143 – Status General – New Hostname

3.23 eSIM Configuration

Starting with firmware release version 3.6.0, eSIM will allow for dual network registration for better connectivity and reliability. A WAN source and a valid eSIM activation code will be needed to proceed. To enable this feature, do the following in Mission Control.

Note: Up to 4 eSIM profiles can be configured and supported.

3.23.1.1 eSIM Manage

A WAN source connection will be required for eSIM configuration. If there is no physical connection on the WAN port, there will be no IP address assigned, and the **RX** and **TX** packet counters will not be actively incrementing or all zeroes as seen in Mission Control under the **Overview > Interfaces** section.

Modem Status

Connection Mode

5G+

Home Network

FirstNet

Current SIM in use

physical SIM

Current APN in use

firstnet-broadband

LTE

5G

Connection Status

Connected

Connected

Band

14

77

CID (Serving Cell ID)

79474863

79474863

PCI (Physical Cell ID)

388

85

Bandwidth

10

80

RSRP

-91

-112

RSRQ

-11

-18

RSSI

-65

-93

TX Power

20

2

MIMO status

1x1-SISO

1x1-SISO

Networking

DHCP Leases

Active DHCPv4 Leases

Hostname

IPv4 address

MAC address

Lease time remaining

LGgram

192.168.113.173

00:24:9B:2D:48:17

11h 59m 18s

LPORCHAS-LT

192.168.113.140

BC:F4:D4:6F:D8:C1

11h 54m 41s

Active DHCPv6 Leases

Host

IPv6 address

DUID

Lease time remaining

There are no active leases

Interfaces

Type

MAC

RX

TX

IPv4

IPv6

GUEST

0 B (0 Pkts.)

0 B (0 Pkts.)

LAN

34:BA:9A:C3:5D:D0

692.52 KB
(4388 Pkts.)

5.36 MB
(3954 Pkts.)

192.168.113.1/24

fdca:cd5b:b5b2:1/64

WAN

34:BA:9A:C3:5D:D3

0 B (0 Pkts.)

0 B (0 Pkts.)

WAN6

34:BA:9A:C3:5D:D3

0 B (0 Pkts.)

0 B (0 Pkts.)

WWAN

2E:B1:25:77:E6:02

549.27 KB
(2139 Pkts.)

345.54 KB
(2581 Pkts.)

10.22.119.146/30

2600:382:3916:6f4a:68f2:bdad:b4e2:cd85/64

Figure 144 – Interfaces – WAN Packet Counters at zero or not incrementing

1. Start by connecting a WAN source to the AC-MegaFi 2 WAN/LAN2 port. This is required in order for the eSIM to download its profile. This will not work over a cellular connection (WWAN). Establishing a physical WAN connection will force a failover from WWAN to WAN, unless the device is already set to prefer the WAN interface as its primary connection. You will notice that packets will begin to increase along with an assigned IP address on the WAN interface.

Modem Status

Connection Mode	5G	
Home Network	FirstNet	
Current SIM in use	physical SIM	
Current APN in use	firstnet-broadband	
	LTE	5G
Connection Status	Connected	Not connected
Band	14	
CID (Serving Cell ID)	79474863	
PCI (Physical Cell ID)	388	
Bandwidth	10	
RSRP	-90	
RSRQ	-10	
RSSI	-63	
TX Power		
MIMO status	1x1-SISO	not_attach

Networking

DHCP Leases

Active DHCPv4 Leases

Hostname	IPv4 address	MAC address	Lease time remaining
LGgram	192.168.113.173	00:24:9B:2D:48:17	11h 52m 23s
LPORCHAS-LT	192.168.113.140	BC:F4:D4:6F:D8:C1	11h 46m 47s

Active DHCPv6 Leases

Host	IPv6 address	DUID	Lease time remaining
There are no active leases			

Interfaces

Type	MAC	RX	TX	IPv4	IPv6
GUEST		0 B (0 Pkts.)	0 B (0 Pkts.)		
LAN	34:BA:9A:C3:5D:D0	1.33 MB (7667 Pkts.)	10.89 MB (8216 Pkts.)	192.168.113.1/24	fdca:cd5b:b5b2::1/64
WAN	34:BA:9A:C3:5D:D3	713 MB (49945 Pkts.)	44712 KB (3956 Pkts.)	172.16.8.168/22	
WAN6	34:BA:9A:C3:5D:D3	713 MB (49945 Pkts.)	44712 KB (3956 Pkts.)		
WWAN	2E:B1:25:77:E6:02	625.85 KB (2733 Pkts.)	1.30 MB (12355 Pkts.)	10.22.119.146/30	2600:382:3916:6f4a:68f2:bdad:b4e2:cd85/64

Figure 145 – Interfaces – WAN Packet Counters incrementing with assigned IP address

2. In Mission Control, navigate to **Overview > System Settings** under **Admin Tools**.
3. Click on the **Expert Configuration** button to enter Expert Configuration mode.

Admin Tools

System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Save & Apply **Save** **Reset**

Figure 146 – System Settings – Expert Configuration

- A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.

192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

OK **Cancel**

Figure 147 – Confirmation to Enter Expert Configuration mode

- The left-pane menu exposes pages only available in Expert Configuration mode. Navigate to **System > eSIM Manage**.




Figure 148 – eSIM Manage

Note: The warnings at the top will disappear as you configure and commit the necessary parameters.

6. Click on the **set eSIM as Primary SIM** button and wait about a minute to allow for the device to switch to eSIM. This may take a few minutes. The informational message at the top will indicate **Switching to eSIM... please wait**.




Figure 149 – eSIM Manage – set eSIM as Primary SIM

7. After the short wait, you will see that there is no enabled profile, no profiles listed, and a new and third section to **Add eSIM Profile**.

eSIM Manage

Currently Enabled Profile

There is no enabled profile

eSIM Profile List

There are no profiles

Add eSIM Profile

QR code upload

Activation Code

Confirmation Code

Download eSIM Profile

Figure 150 – eSIM Manage – no enabled nor listed profile, with a section to Add eSIM Profile

Note: If after several minutes, you do not see the above, refresh the page.

Note: The cellular signal strength bars on the top right corner will disappear. This is normal.

8. An eSIM Profile can be added by uploading a downloaded QR code or by manually entering your eSIM **Activation Code** and **Confirmation Code** (optional), then click on the **Download eSIM profile** button.

Note: You may have received some instructions from the eSIM vendor. Please read and follow their instructions before proceeding with this step.

eSIM Manage

Currently Enabled Profile

There is no enabled profile

eSIM Profile List

There are no profiles

Add eSIM Profile

8a **QR code upload**

8b Activation Code

Confirmation Code

8c **Download eSIM Profile**

Figure 151 – Add eSIM Profile via QR code upload or manually

8a. If a QR code was downloaded, click on **QR code upload**, navigate to the file and follow the instructions to upload the Activation Code and the optional Confirmation Code from the QR code file. Then skip to step 8c.

8b. If you prefer to manually enter the Activation Code and the optional Confirmation Code, enter the codes, then go to step 8c.




Figure 152 – Add eSIM code manually – no Confirmation code used as it is optional

8c. Click on the **Download eSIM Profile** button.

9. The eSIM profile begins to download and may take over 30 seconds to complete. Do not perform any other actions during this time.




Figure 153 – eSIM Manage – Downloading profile...

10. After the eSIM profile completes downloading, an informational message lets you know the **modem is rebooting... please wait**.




Figure 154 – eSIM Manage – Info: modem is rebooting... please wait

After the modem completes rebooting, the new eSIM profile will appear as **Profile ID 1**. Validate the **eSIM ICCID** with your eSIM provider. Notice that the **Profile Class** is **operational** for this profile. The **Profile Name** may vary by provider with an actual name, or it may be represented with the **eSIM ICCID** number as shown in this example. Enter an optional nickname if the field provided if you wish to keep track of multiple eSIM profiles.




Figure 155 – eSIM Manage – Completed eSIM Profile and operational

11. Next to **Action**, click on the **Enable** button for **Profile ID 1** for your newly downloaded eSIM profile.

eSIM Manage

Currently Enabled Profile

There is no enabled profile

eSIM Profile List

Profile ID	1
eSIM ICCID	89017901028907035371
Profile Name	89017901028907035371
Profile Nickname	Optional - Enter profile custom name
Profile Class	operational
Action	Enable Delete

Add eSIM Profile

Activation Code

Confirmation Code

Figure 156 – eSIM Manage – Enable eSIM

- Wait for about 10 seconds for the confirmation. Do not perform any other actions during this time.

Enable profile...

This operation will take over 10 seconds. Do not perform any other actions during this time.

Figure 157 – eSIM Manage – Wait for eSIM Profile to enable

- After the wait, the **Currently Enabled Profile** reflects the eSIM profile in use. After about another minute, the cellular strength signal bars will come back, and the 'e' symbol on the LCD display is illuminated, indicating the device is eSIM ready.




Figure 158 – eSIM Manage – eSIM Profile in use

14. This process automatically configures the **eSIM custom APN** as shown in **Overview > Modem Status** section and has made the eSIM the only SIM in use over the physical SIM as shown further below under Admin Tools/System Settings.




Figure 159 – Overview – Modem Status – eSIM custom APN




Figure 160 – Overview – Admin Tools – Primary SIM = eSIM, and set to automatic APN selection

15. The WAN source can be disconnected, and internet connectivity will flow through the eSIM.
16. In the **Overview > Interfaces** section, the IP address for the eSIM will be displayed under the **IPv4 WWAN** interface.

Type	MAC	RX	TX	IPv4	IPv6
GUEST		0 B (0 Pkts.)	0 B (0 Pkts.)		
LAN	34:BA:9A:C3:5D:D0	4.17 MB (13917 Pkts.)	29.25 MB (19163 Pkts.)	192.168.113.1/24	fdca:cd5b:b5b2::1/64
WAN	34:BA:9A:C3:5D:D3	46.11 MB (168453 Pkts.)	4.65 MB (17323 Pkts.)		
WAN6	34:BA:9A:C3:5D:D3	46.11 MB (168453 Pkts.)	4.65 MB (17323 Pkts.)		
WWAN	BE:0E:AD:BD:EB:01	146.04 KB (792 Pkts.)	234.17 KB (1632 Pkts.)	100.76.115.193/30	

Active Connections: 244 / 15360 (1%)

Figure 161 – Interfaces – WWAN IP address

17. If you prefer to make the physical SIM the primary SIM and the eSIM the standby SIM, do the following in Mission Control via **Overview > Admin Tools**. Go to the **Primary SIM** drop-down menu and select **Automatic** from the list.




Figure 162 – Admin Tools – Setting Primary SIM to Automatic

18. Hidden options will appear. Adjust the SIM settings as needed, otherwise the default settings can be used as is.

Table 6 – SIM settings in Admin Tools

SIM Setting	Default setting	Other Options	Description
Primary SIM	physical SIM	eSIM or Automatic	Physical SIM – used when an eSIM is not in use. eSIM – used when a physical SIM is not in use. Automatic – select for failover between physical and eSIM

Physical SIM APN selection or eSIM APN selection	Automatic	Custom - When Custom is selected a hidden field appears called Physical SIM custom APN or eSIM custom APN	This field appears for Primary SIM set to either physical SIM or eSIM. Automatic – set when an eSIM profile is enabled and auto-configures its APN. Custom – can customize the APN when selected. The custom APN field is otherwise hidden.
Preferred SIM – normally hidden until Primary SIM is set to Automatic	Physical SIM	eSIM	Select the preferred SIM
Switch after losing connection (seconds) – normally hidden until Primary SIM is set to Automatic	60	15, 30, 90, 120	Select duration of time without connection before failover occurs from the drop-down list
Physical SIM APN selection – normally hidden until Primary SIM is set to Automatic	Automatic	Custom	Automatic – APN will automatically get configured Custom – customize the APN
eSIM APN selection – normally hidden until Primary SIM is set to Automatic	Automatic	Custom	Automatic – APN will automatically get configured Custom – customize the APN

This example shows the default settings when Automatic is selected for Primary SIM :

Admin Tools

System Settings

Primary SIM	Automatic	▼
Preferred SIM	physical SIM	▼
Switch after losing connection (seconds)	60	▼
Physical SIM APN selection	Automatic	▼
eSIM APN selection	Automatic	▼

Figure 163 – Admin Tools – Primary SIM set to Automatic and default SIM settings

- Click on **Save & Apply** at the bottom. The LCD display will indicate that the physical SIM is now active with a 'p' on the top right corner, but it may take Mission Control a few minutes to catch up and properly display this. After a few minutes, check in **Overview > Modem Status** and validate which **Current SIM in use** is **physical SIM**.

Modem Status	
Connection Mode	5G+
Home Network	ATT
Current SIM in use	physical SIM
Current APN in use	internet

Figure 164 – Modem Status – Current SIM in use

3.23.2 Disable and Delete eSIM Profile

If a currently enabled eSIM profile is no longer needed or you would like to use a different profile, do the following in Mission Control to disable and/or delete it.

Disabling the eSIM profile keeps it on the device Profile List for later use, while deleting the eSIM profile removes it from the Profile List.

Note: Deleting the eSIM profile will not remove it from the device's memory, and currently it will automatically get added back to the Profile List after toggling the Primary SIM between Physical and eSIM.

To Disable the eSIM Profile:

1. Navigate to the **eSIM Manage** page.
2. If the **Primary SIM** setting is set to **Automatic** as described above or set to **physical SIM**, it is necessary to **set eSIM as Primary SIM** to manage eSIM profiles. Click on set **eSIM as Primary SIM** to begin. The Info message reads: Switching to eSIM... please wait. Allow a few minutes for the setting to take place.

Warning: To manage eSIM it is necessary to set 'eSIM' as Primary SIM
Dismiss

Overview
Status
System
Router Password
Startup
Scheduled Tasks
Configuration
GPS Configuration
eSIM Manage
VPN Configuration
Remote Configuration
Network
Logout

eSIM Manage

Currently Enabled Profile

Profile ID	1
eSIM ICCID	89017901028907035371
Profile Name	89017901028907035371
Profile Nickname	Optional - Enter profile custom name
Profile Class	operational

eSIM Profile List

There are no profiles

set eSIM as Primary SIM

Figure 165 – eSIM Manage – set eSIM as Primary SIM

3. Select the **Disable** button next to **Action** of the **Currently Enabled Profile**.

eSIM Manage

Currently Enabled Profile

Profile ID	1
eSIM ICCID	89017901028907035371
Profile Name	89017901028907035371
Profile Nickname	Optional - Enter profile custom name
Profile Class	operational
Action	Disable

eSIM Profile List

There are no profiles

Add eSIM Profile

QR code upload

Activation Code

Enter activation code

Confirmation Code

Optional - Enter confirmation code

Download eSIM Profile

Figure 166 – eSIM Manage – Disable Currently Enabled Profile

- This action will take about 10 seconds to complete. If the MegaFi was currently active on eSIM, failover to physical SIM will take longer. Once complete, the eSIM profile is now under eSIM Profile List and it is ready to **Enable** or **Delete** from here, or you may enable another eSIM profile and keep this for later use.

Disable profile...

This operation will take about 10 seconds. Please wait...

Figure 167 – Disable Currently Enabled Profile – allow 10 seconds

eSIM Manage

Currently Enabled Profile

There is no enabled profile

eSIM Profile List

Profile ID	1
eSIM ICCID	89017901028907035371
Profile Name	89017901028907035371
Profile Nickname	Optional - Enter profile custom name
Profile Class	operational
Action	Enable Delete

Add eSIM Profile

Activation Code

Confirmation Code

Figure 168 – Disabled eSIM Profile in List

To Delete the eSIM Profile:

- If you want to delete the eSIM profile from the **eSIM Profile List**, select **Delete**.

Important: An active internet connection is required to notify the eSIM management server. Otherwise, the eSIM may become unrecoverable or non-downloadable again. This is best accomplished with an Internet source connected to the WAN interface.

Note: Deleting the eSIM profile only deletes it from the eSIM Profile List. The eSIM profile will still be intact within memory of the device.

eSIM Manage

Currently Enabled Profile

There is no enabled profile

eSIM Profile List

Profile ID	1
eSIM ICCID	89017901028907035371
Profile Name	89017901028907035371
Profile Nickname	Optional - Enter profile custom name
Profile Class	operational
Action	Enable Delete

Add eSIM Profile

QR code upload

Activation Code

Enter activation code

Confirmation Code

Optional - Enter confirmation code

Download eSIM Profile

Figure 169 – Delete eSIM Profile

192.168.113.1 says

Deleting the eSIM profile requires an active internet connection to notify the eSIM management server.

If the device is offline, the deletion will only occur locally and the operator may still treat the profile as active.

In this case the profile may not be recoverable or downloadable again.

Do you really want to delete profile 1?

OK

Cancel

Figure 170 – Delete eSIM Profile Warning

- This action will take about 10 seconds to complete. Do not perform any other actions during this time.

Delete profile...

This operation will take over 10 seconds. Do not perform any other actions during this time.


Figure 171 – Delete eSIM Profile – allow 10 seconds

3.23.3 Purge eSIM Profile

In case a MegaFi is repurposed or needs to be returned for repair or replacement, and the user wants to completely erase all data as well as any eSIM profile(s) data, a simple factory reset will not remove eSIM profile data as it will be kept in memory. To completely erase eSIM profile data, a user will need to first enable **Purge eSIM profiles...**, then follow through with a factory reset. Do the following in Mission Control to accomplish this.

Note: Proceed with purge of eSIM profiles with caution. Purging the eSIM profile requires an active internet connection to notify the eSIM management server. If the device is offline, the purge will only occur locally, and the operator may still treat the profile as active. In this case the profile may not be recoverable or downloadable again.

1. Connect a WAN source to the WAN port of the MegaFi device. A purge of the eSIM profile requires this.
2. Login to Mission Control and navigate to **Expert Configurations > System > eSIM Manage**.
3. Locate the target eSIM profile and select **Disable**.
4. Now select the **Delete** button next to the target eSIM profile.
5. Navigate to **System > Configuration**.
6. Under the Other section, select **Enabled** from the drop-down menu for the **Purge eSIM profiles if Factory Defaults** setting.




Other	
Hostname	Airgain
Reboot Offline Time (minutes)	Disabled
Band Lock	Default Band Configuration
Band 1	Disabled - Mobile applications
Band 30	Enabled - Fixed applications
Maximize Band 14 usage	Disable
Failover Primary Connection	WAN - Internet Connection
Failover Switch Time (seconds)	15
dB Threshold as Failover Criteria	Enabled
dB Threshold Value	-120
dB Hysteresis Value	10
Purge eSIM profiles if Factory Defaults	Enabled
Sensors Temperature Unit	Disabled
Restore Configuration	
Build Information	

Figure 172 – eSIM Profile Purge setting

7. Click **Save & Apply** at the bottom.
8. Make sure the MegaFi has a WAN internet source connected.

9. Right under **Purge eSIM profiles if Factory Defaults**, click on the **Factory Defaults** button next to **Restore Configuration** and confirm by clicking on **OK** on the popup box to proceed with this action.



Other	
Hostname	Airgain
Reboot Offline Time (minutes)	Disabled
Band Lock	Default Band Configuration
Band 1	Disabled - Mobile applications
Band 30	Enabled - Fixed applications
Maximize Band 14 usage	Disable
Failover Primary Connection	WAN - Internet Connection
Failover Switch Time (seconds)	15
dB Threshold as Failover Criteria	Enabled
dB Threshold Value	-120
dB Hysteresis Value	10
Purge eSIM profiles if Factory Defaults	Disabled
Sensors Temperature Unit	Fahrenheit
Restore Configuration	Factory Defaults

Build Information

Figure 173 – Restore Configuration – Factory Defaults button

10. After the device boots up, check the **eSIM Manage** page.
11. Click on **set eSIM as Primary SIM** and verify that no eSIM profiles exist within this page after the action is completed.
12. Check back in **System > Configuration > Other** and confirm that the **Purge eSIM profiles if Factory Default = Disabled** (default setting).

3.24 Download Troubleshooting Files

A feature was added to the Admin Tools area where a collection of troubleshooting files can be downloaded from the MegaFi. A tarball file is created and this can then be easily forwarded to the Airgain support team for further analysis. Do the following in Mission Control to download this file.

1. In Mission Control, navigate to **Overview > System Settings** under **Admin Tools**.




Figure 174 – System Settings – Expert Configuration

2. Click on **Save to Archive** next to **Download Troubleshooting Files** to download the collection of files.
3. Look in the Downloads folder of your computer. The file will be called **troubleshooting.files.tar.gz**.

3.25 Firewall

While in NAT mode, the Firewall of the AC-MegaFi 2 device is active and blocks unsolicited incoming connections from the WWAN/WAN interfaces unless you explicitly allow them.

There are two methods in which you can allow incoming connections through the Firewall, either by a **Port Forward** or a **Traffic Rule**. Depending on the need, a Port Forward allows specific traffic from the WWAN/WAN to LAN and translate it to an internal host. A Traffic Rule allows, blocks, or redirects traffic without doing NAT. Do the following in Mission Control to create a Port Forward or Traffic Rule.


The typical caveats for implementing these rules are the following:

1. The AC-MegaFi 2 device is in NAT mode
2. The AC-MegaFi 2 device has a SIM card with a static and or public IP address

3.25.1 Port Forward

A Port Forward creates a NAT rule that takes traffic arriving on the WAN interface and forwards it to a device inside your LAN. To create a Port Forward rule, do the following in Mission Control.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.



Admin Tools


System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Save & Apply ▼ **Save** **Reset**

Figure 175 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.



192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

OK **Cancel**

Figure 176 – Confirmation to Enter Expert Configuration mode

- Navigate to **Network > Firewall**. The landing page is General Settings. Select **Port Forwards** at the top.

General Settings **Port Forwards** Traffic Rules NAT Rules IP Sets

Firewall - Zone Settings

The firewall creates zones over your network interfaces to control network traffic flow.

General Settings

Enable SYN-flood protection ☐

Drop invalid packets ☐

Input

Output

Forward

Routing/NAT Offloading

Experimental feature. Not fully compatible with QoS/SQM.

Software flow offloading ☐

Software based offloading for routing/NAT

Zones

Zone ⇒ Forwards	Input	Output	Forward	Masquerading	
lan ⇒ wan swvpn	accept	accept	accept	☐	Edit Delete
wan ⇒ REJECT	reject	accept	reject	☒	Edit Delete
guest ⇒ wan	reject	accept	reject	☐	Edit Delete
swvpn ⇒ lan	accept	accept	accept	☒	Edit Delete

Figure 177 – Firewall – General Settings

- Click the **Add** button to add a Port Forward rule.

General Settings **Port Forwards** Traffic Rules NAT Rules IP Sets

Firewall - Port Forwards


Port forwarding allows remote computers on the Internet to connect to a specific computer or service within the private LAN.

Port Forwards

Name	Match	Action	Enable
This section contains no values yet			

Figure 178 – Firewall – Port Forwards Add

6. Within General Settings of the Port Forwards pop-up window the following options are available:
 - **Name** – name of the Port Forward rule
 - **Restrict to address family** – options are automatic (default), IPv4 only, IPv6 only
 - **Protocol** – options are Any, TCP, UDP, ICMP, and custom. Both TCP and UDP are selected by default
 - **Source zone** – options are guest, lan, swvpn, wan (wan, wan6, wwan); wan is selected by default
 - **External port** – enter the port number or range of port numbers expected
 - **Destination zone** - options are **unspecified**, **guest**, **lan** (default), **swvpn**, **wan** (wan, wan6, wwan)
 - **Internal IP address** – select **any** or the desired destination device by internal IP address, MAC address or hostname from the drop-down menu. There is an option to enter a custom value as well.
 - **Internal port** – enter the expected port number or port number range or redirect to a different port number on the internal host



Firewall - Port Forwards - Unnamed forward

General Settings 1 **Advanced Settings**

Name: Unnamed forward

Restrict to address family: automatic

Protocol: TCP, UDP

Source zone: wan, wan: wan6: wwan:

External port:

Destination zone: lan, lan:

Internal IP address: any

Internal port: any

Match incoming traffic directed at the given destination port or port range on this host

Redirect matched incoming traffic to the specified internal host

Redirect matched incoming traffic to the given port on the internal host

Dismiss Save

Figure 179 – Firewall – Port Forwards General Settings

7. In the following example, we created a Port Forward rule to allow an incoming RDP (Remote Desktop Protocol) connection, which uses the TCP protocol, to a specific PC computer on the LAN using the typical RDP port of 3389. We match the external and internal port to 3389 as it will not change.

Firewall - Port Forwards - Unnamed forward

General Settings
Advanced Settings

Name
Restrict to address family
Protocol
Source zone
External port
Destination zone
Internal IP address
Internal port

Allow-RDP-Hostname
automatic
TCP
wan wan: wan6: wwan:
3389
lan lan:
192.168.113.134 (LPORCHAS-LT.lan)
3389

Match incoming traffic directed at the given destination port or port range on this host
Redirect matched incoming traffic to the specified internal host
Redirect matched incoming traffic to the given port on the internal host

Dismiss
Save

Figure 180 – Firewall – Port Forwards RDP example

- Click on **Save** then **Save & Apply** on the main **Firewall - Port Forwards** page.
- A remote user should now be able to successfully connect to the local PC computer via an RDP connection. In the RDP connection image example below, the user is entering the public-static IP address of the AC-MegaFi 2 device which comes from the SIM card.





Figure 181 – Remote user preparing an RDP connection

3.25.2 Traffic Rule

A Traffic Rule simply allows, blocks or redirects traffic between firewall zones. For example, is the IPsec VPN endpoint and we need to create a traffic rule to ensure VPN traffic can pass through NAT. NAT-T or NAT-Traversal protocols UDP port 4500 and UDP port 500 will need to be allowed inbound. We'll show how to create one of these rules. The other rule can be similarly created using the other port number.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.



Admin Tools


System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Save & Apply Save Reset

Figure 182 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.



192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

OK Cancel

Figure 183 – Confirmation to Enter Expert Configuration mode

4. Navigate to **Network > Firewall**. The landing page is General Settings. Select **Traffic Rules** at the top.

General Settings
Port Forwards
Traffic Rules
NAT Rules
IP Sets

Firewall - Zone Settings

The firewall creates zones over your network interfaces to control network traffic flow.

General Settings

Enable SYN-flood protection
☒

Drop invalid packets
☐

Input
accept

Output
accept

Forward
reject

Routing/NAT Offloading

Experimental feature. Not fully compatible with QoS/SQM.

Software flow offloading
☐

☐ Software based offloading for routing/NAT

Zones

Zone ⇒ Forwardings	Input	Output	Forward	Masquerading	
lan ⇒ wan swvpn	accept	accept	accept	☐	Edit Delete
wan ⇒ REJECT	reject	accept	reject	☒	Edit Delete
guest ⇒ wan	reject	accept	reject	☐	Edit Delete
swvpn ⇒ lan	accept	accept	accept	☒	Edit Delete

Add

Save & Apply
Save
Reset

Figure 184 – Firewall – General Settings

5. A predefined set of Traffic Rules are already configured by default. Scroll to the bottom and click on the **Add** button to add a new Traffic Rule.

General Settings
Port Forwards
Traffic Rules
NAT Rules
IP Sets

Firewall - Traffic Rules

Traffic rules define policies for packets traveling between different zones, for example to reject traffic between certain hosts or to open WAN ports on the router.

Traffic Rules

Name	Match	Action	Enable
Allow-DHCP-Renew	Incoming IPv4 , protocol UDP From wan To this device , port 68	Accept input	☒ Edit Delete
Allow-Ping	Incoming IPv4 , protocol ICMP From wan To this device	Accept input	☒ Edit Delete
Allow-IGMP	Incoming IPv4 , protocol IGMP From wan To this device	Accept input	☒ Edit Delete
Allow-DHCPv6	Incoming IPv6 , protocol UDP From wan To this device , port 546	Accept input	☒ Edit Delete
Allow-MLD	Incoming IPv6 , protocol ICMP From wan , IP fe80::/10 To this device	Accept input	☒ Edit Delete
Allow-ICMPv6-Input	Incoming IPv6 , protocol ICMP From wan To this device	Accept input	☒ Edit Delete
Allow-ICMPv6-Forward	Forwarded IPv6 , protocol ICMP From wan To any zone Limit matching to 1000 packets per second	Accept forward	☒ Edit Delete
Allow-IPSec-ESP	Forwarded IPv4 and IPv6 , protocol IPSEC-ESP From wan To lan	Accept forward	☒ Edit Delete
Allow-ISAKMP	Forwarded IPv4 and IPv6 , protocol UDP From wan To lan , port 500	Accept forward	☒ Edit Delete
Support-UDP-Traceroute	Incoming IPv4 , protocol UDP From wan To this device , port 33434-33689	Drop input	☐ Edit Delete
Allow-Remote-HTTPS	Incoming IPv4 and IPv6 , protocol TCP From wan To this device , port 443	Reject input	☒ Edit Delete
Allow-DNS-guest	Incoming IPv4 and IPv6 , protocol TCP, UDP From guest To this device , port 53	Accept input	☒ Edit Delete
Allow-DHCP-guest	Incoming IPv4 , protocol UDP From guest To this device , port 67	Accept input	☒ Edit Delete
Allow-NAT-T	Forwarded IPv4 and IPv6 , protocol UDP From wan To lan , port 4500	Accept forward	☒ Edit Delete


[Add](#)

Save & Apply
Save
Reset

Figure 185 – Firewall – General Settings

6. Within General Settings of Traffic Rules pop-up window the following options are available:

- **Name** – name of the Traffic Rule
- **Protocol** – options are **Any**, **TCP**, **UDP**, **ICMP**, **IGMP**, **IPSEC-ESP**, and **custom**. Both **TCP** and **UDP** are selected by default
- **Source zone** – options are **Device(output)**, **Any zone(forward)**, **guest**, **lan**, **swvpn**, **wan** (wan, wan6, wwan); **Device(output)** is selected by default
- **Source address** – choose from the drop-down menu or enter a custom IP address
- **Source port** – enter a source port number
- **Output zone** – options are **Any zone** (default), **guest**, **lan**, **swvpn**, **wan** (wan, wan6, wwan); Any zone is selected by default
- **Destination address** - choose from the drop-down menu or enter a custom IP address
- **Destination port** – enter a source port number
- **Action** – options are **accept** (default), **drop**, **reject**, **don't track**, **assign conntrack helper**, **apply firewall mark**, **XOR firewall mark**, **DSCP classification**



Firewall - Traffic Rules - Unnamed rule

General Settings Advanced Settings Time Restrictions

Name	Unnamed rule
Protocol	TCP UDP
Source zone	Device(output)
Source address	-- add IP --
Source port	any
Output zone	Any zone
Destination address	-- add IP --
Destination port	any
Action	accept

Dismiss Save

Figure 186 – Firewall – Traffic Rules General Settings

7. In the following example, we created a Traffic Rule to allow or accept inbound NAT-T traffic on port 4500, which uses the UDP protocol, to the LAN zone.

Firewall - Traffic Rules - Unnamed rule

General Settings
Advanced Settings
Time Restrictions

Name	Allow-NAT-T
Protocol	UDP
Source zone	wan wan: wan6: wwan:
Source address	-- add IP --
Source port	any
Destination zone	lan lan:
Destination address	-- add IP --
Destination port	4500
Action	accept

Dismiss
Save

Figure 187 – Firewall – Traffic Rules NAT-T (port 4500) example

8. Click on **Save** then **Save & Apply** on the main **Firewall - Traffic Rules** page.
9. Following the same steps, create another Traffic Rule for port 500, only change the name and this will complete what is needed for NAT-T.

3.26 Firewall Diagnostics

Firewall Diagnostics can be used to help troubleshoot blocked traffic that is expected inbound through the MegaFi firewall. Turn this feature on for the selected duration to help analyze this traffic that is not normally recorded in the system log. Do the following in Mission Control.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.

Admin Tools

System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

[Save & Apply](#) [Save](#) [Reset](#)

Figure 188 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.

192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

[OK](#) [Cancel](#)

Figure 189 – Confirmation to Enter Expert Configuration mode

4. Navigate to **Status > Firewall Diagnostics**.

Firewall Diagnostics

Temporary logging of blocked traffic

Duration: 1 minute ▼

Logging is disabled

Start Logging

No blocked events logged yet.

Figure 190 – Firewall Diagnostics

5. Select the duration from the drop-down menu from the 1, 3, 5, 10, 15, or 30 minutes.

Firewall Diagnostics

Temporary logging of blocked traffic

Duration: 1 minute ▼

Logging is 1 minute

3 minutes

Start Log

5 minutes

10 minutes

15 minutes

30 minutes

No blocked events logged yet.

Figure 191 – Firewall Diagnostics – Duration options

6. Then click on **Start Logging** to start. A timer will commence and start to count down. Press **Stop Logging** to prematurely stop the action. Induce perceived incoming traffic during this time frame to see any blocked traffic.

Firewall Diagnostics

Temporary logging of blocked traffic

Duration: 1 minute ▼

Active, will stop in 0 min 58 sec

Stop Logging

No blocked events logged yet.

Figure 192 – Firewall Diagnostics – Count down timer and Stop Logging – no blocked events

7. If there are any blocked events, the blocked events will be displayed below under Recently Blocked Events as well as in the System Log.




Figure 193 – Firewall Diagnostics – Recently Blocked events

8. Navigate to **Status > System Log** and scroll all the way down the System Log to review any rejected entries.




Figure 194 – System Log – Blocked events

In the example above, the rejected or blocked events were blocked at the `wwan0` interface and destined to IP address `107.89.21.27` on port `443` using TCP protocol. The source of this traffic was noted as coming from an IP address of `23.117.226.127`.

This type of traffic is typical of an incoming HTTPS remote access request to the destined device. The suggestion is given as to **Allow incoming TCP port 443**, but only do so if you trust the source.

Hint: There is a predefined Traffic Rule to **Allow-Remote-HTTPS** in the MegaFi Firewall – Traffic Rules table that is set to **Reject**. The rule can easily be modified to **Accept** by unchecking the box next to **Reject input** and **Save & Apply**.




Figure 195 – Firewall Traffic Rules – Allow-Remote-HTTPS

3.27 Smart Queue Management (SQM QoS)

Bufferbloat is most evident when a connection is heavily loaded with downloads or uploads. This causes increased latency (ping), resulting in poor performance for realtime tasks like VoIP, Wi-Fi calling, video chat, lag in online gaming, and generally makes the internet less responsive. This latency can be mitigated with SQM.

This can be implemented in Mission Control as follows.


Preparation: Measure Your Current Speed and Latency

Before you can optimize your network, you need to test its initial state.

- To maximize performance most modern devices will benefit from enabling Packet Steering (all CPUs) under **Network > Interfaces > Global network options**.
- When your internet is unused run a speed test at [Waveform](#), [Speedtest](#), [Libre QOS](#) or [Cloudflare](#). This is to determine your peak download/upload speeds, latency, and grade your bufferbloat. Where applicable save the results so that you can more easily carry out before/after comparisons.
- To help to eliminate network bottlenecks, you may wish to use more than one speedtest app.
- Ensure that your local network, system and web browser are otherwise lightly loaded or preferably completely idle.
- If you are using this OpenWrt device as an [Extender, Repeater, or Bridge](#), test your upstream router (OpenWrt or otherwise) and determine if an issue is present there first.

- If you are on a [wireless AP](#), test your upstream router separately. If your AP wifi driver supports AQL limits (e.g. [mt76](#) does) adjust/reduce those separately to improve wifi latency.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.



Admin Tools


System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Save & Apply Save Reset

Figure 196 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.



192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

OK Cancel

Figure 197 – Confirmation to Enter Expert Configuration mode

4. Navigate to **Network > SQM QoS**
5. In the **Basic Settings** tab:
 - Check the **Enable** box
 - Set the **Interface** to your internet (WAN, WWAN, etc) link in the dropdown. Check Network → Interfaces if you need to determine your WAN port.
 - Enter your **Download** and **Upload** speeds to 90% of the results you tested during Preparation.
6. In the **Queue Discipline** tab:
 - Choose *cake* as the Queueing Discipline (or *fq_codel*)
 - Choose *piece_of_cake.qos* as the Queue Setup Script
 - Advanced Configuration may be left unchecked
7. In the **Link Layer Adaptation** tab, select your link type and overhead (setting mpu is optional):
 - *VDSL* - choose **Ethernet**, and set overhead 34 (or 26 if you're not using PPPoE) (mpu 68). If the link is 100 Mbps Ethernet set overhead 42 (mpu 84).
 - *DSL of any other type* - choose **ATM**, and set overhead 44 (mpu 96).
 - *DOCSIS Cable* - choose **Ethernet**, and for rates < 760 Mbps set overhead 22 (mpu 64), for rates >= 760 Mbps set overhead 42 (mpu 84).
 - *Fiber* - choose **Ethernet**, and set overhead 44 (mpu 84).
 - *Ethernet* - choose **Ethernet**, and set overhead 44 (mpu 84).
 - If you are unsure, it's better to overestimate, choose **Ethernet**, and set overhead 44 (mpu 96).
8. Click **Save & Apply**.

Done! You can confirm results by re-running the speedtest. Any increased ping during download/uploads will now be minimal.

3.28 Time Zone

By default the MegaFi is set to UTC. The UTC time zone is replicated in System Logs, and MegaPortal timestamps.

Do the following in Mission Control to change the Time Zone.

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.

Figure 198 – System Settings – Expert Configuration


3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.

Figure 199 – Confirmation to Enter Expert Configuration mode

4. Navigate to **System > Configuration > Time Zone**

Figure 200 – Time Zone setting

- Choose the preferred time zone from the drop-down menu.



Time Zone

Timezone
Other

Hostname
 Reboot Offline Time (minutes)
 Band Lock
 Band 1
 Band 30
 Maximize Band 14 usage
 Failover Primary Connection
 Failover Switch Time (seconds)
 dB Threshold as Failover Criteria
 dB Threshold Value
 dB Hysteresis Value
 Purge eSIM profiles if Factory Defaults
 Sensors Temperature Unit
 Restore Configuration

Build Information

Firmware Version: v3.7.0.22
 Target board: MegaFi_2

Default / UTC (UTC+00:00)
 America / Lima (UTC-05:00)
America / Los Angeles (UTC-08:00 / DST)
 America / Lower Princes (UTC-04:00)
 America / Maceio (UTC-03:00)
 America / Managua (UTC-06:00)
 America / Manaus (UTC-04:00)
 America / Marigot (UTC-04:00)
 America / Martinique (UTC-04:00)
 America / Matamoros (UTC-06:00 / DST)
 America / Mazatlan (UTC-07:00)
 America / Menominee (UTC-06:00 / DST)
 America / Merida (UTC-06:00)
 America / Metlakatla (UTC-09:00 / DST)
 America / Mexico City (UTC-06:00)
 America / Miquelon (UTC-02:00 / DST)
 America / Moncton (UTC-04:00 / DST)
 America / Monterrey (UTC-06:00)
 America / Montevideo (UTC-03:00)
 America / Montserrat (UTC-04:00)
 America / Nassau (UTC-05:00 / DST)

Save & Apply Save Reset

Figure 201 – Time Zone setting menu

- Click on **Save & Apply** to commit the new time zone.

3.29 API Configuration

In the **API Configuration** section, there are three options that can be enabled/disabled. These APIs allow external systems to use https to gather modem status, reboot, or power cycle the MegaFi.

- **MegaFi Reboot API Enabled:** Disabled by default
- **Modem power Cycle API Enabled:** Disabled by default
- **Modem Status API Enabled:** Disabled by default

1. Navigate to **Overview > System Settings** under **Admin Tools**.
2. Click on the **Expert Configuration** button to enter Expert Configuration mode.

Admin Tools

System Settings

Primary SIM	physical SIM
Physical SIM APN selection	Automatic
LAN IP	192.168.113.1
WAN/LAN Port Mode	WAN
Update Firmware	Upload Firmware
Backup Existing Configuration	Save to File
Omit System Passwords	☐
Load Configuration from File	Load File
Change Password	Change Password
Download Troubleshooting Files	Save to Archive
Factory Defaults	Factory Defaults
Vehicle Shutdown Delay	30 seconds
Expert Configuration	Expert Configuration
Reboot	Reboot

Save & Apply **Save** **Reset**

Figure 202 – System Settings – Expert Configuration

3. A pop-up window asks the user to confirm going into Expert Configuration mode. Click **OK** to continue.

192.168.113.1 says

The Expert configuration section contains items that may render the MegaFi inoperative and require a factory reset. Please confirm you want to proceed.

OK **Cancel**

Figure 203 – Confirmation to Enter Expert Configuration mode

4. Navigate to **System > Configuration > API Configuration**

API	
MegaFi Reboot API Enabled	Disabled ▼
Modem Power Cycle API Enabled	Disabled ▼
Modem Status API Enabled	Disabled ▼

Figure 204 – API Configuration

5. Click on the dropdown for the setting you wish to change and select the required option of **Enabled** or **Disabled**.
6. Click on Save & Apply to confirm the change.
7. Once the desired API has been enabled, append the appropriate string to the end of the AC-MegaFi 2's url on a web browser as follows.
 - **/cgi-bin/actions/reboot** – will reboot AC-MegaFi 2 and power cycle the modem
 - **/cgi-bin/actions/power-cycle** – will power cycle the modem
 - **/cgi-bin/actions/modem-status** – will return modem status as json
8. Example: To get modem status with the default AC-MegaFi 2 IP address:
 - Open a web browser and enter the following url: <https://192.168.113.1/cgi-bin/actions/modem-status>



```

{
  "time": 1781046506,
  "status": [
    {
      "name": "Sn_s",
      "value": "250302000025",
      "lastChange": "",
      "lastUpdate": "1781046501"
    },
    {
      "name": "SwVersion_s",
      "value": " v3.7.0.22",
      "lastChange": "",
      "lastUpdate": "1780960608"
    },
    {
      "name": "SystemName_s",
      "value": "MegaFi_2",
      "lastChange": "",
      "lastUpdate": "1780960608"
    },
    {
      "name": "HostName_s",
      "value": "Airgain",
      "lastChange": "",
      "lastUpdate": "1780960608"
    },
    {
      "name": "UpTime_i",
      "value": "85943",
      "lastChange": "",
      "lastUpdate": "1781046507"
    },
    {
      "name": "StatusTime_i",
      "value": "1781046506",
      "lastChange": "",
      "lastUpdate": "1781046506"
    },
    {
      "name": "PdpIpAddr_s",
      "value": "10.113.78.199",
      "lastChange": "",
      "lastUpdate": "1781046506"
    },
    {
      "name": "ModemMacAddr_s",
      "value": "36:FE:00:33:4D:62",
      "lastChange": "",
      "lastUpdate": "1781046506"
    },
    {
      "name": "WwanTxBytes_i",
      "value": "237583656"
    }
  ]
}

```

Figure 205 – Modem Status



4 Customer Support

For any questions, please contact Airgain Support:
connectivity.support@airgain.com.